



MOFFETT

Operator Manual

For the Moffett
Truck-Mounted Forklift
Equipped with Reach Mast



Delivering **Confidence**

TABLE OF CONTENTS

A. STANDARD MACHINE

1. SAFETY CHECKLIST

Safety Notices	1
Safety Introduction	2
Safety Checklist	3

2. INTRODUCTION

About this Operator Manual 13

Machine Models	13
Using This Operator Manual	13
Using The Machine	13

The Moffett Truck-Mounted Forklift 14

Machine Description	14
Concept	14
Major Components	15

Identifying Your Machine 16

Machine Serial Plate	16
----------------------	----

Safety Decals 17

General	17
Safety Decals	18

Instruments And Controls 28

Dash Layout (Standard)	29
Transmission Controls	31
- Drive Controls	31
- STD Pump	31
- Anti-Stall	32
- Automotive Pump	32
- Inching/Brake Pedal	33
Mast And Carriage Controls	34
Hydraulic Control Levers	35

3. CENTRE OF GRAVITY

Basic Principles 36	
Introduction	36
Comparison vs Conventional Forklift	38

4. OPERATING PROCEDURES

Using The Machine	40
Entering Operator's Compartment	40

Over Head Guard (OHG) 41

Rollover 42

Using The Machine	43
Adjusting The Seat	43
Fasten The Seat Belt	43
Starting The Engine	44

Driving Techniques 45

Driving Forward	45
Reversing	45
Turning	45
Parking	45
Operating On Inclines	46
Operating With A Load	46
Operating Without A Load	47

Diff-lock

Operation Of Diff-Lock	48
When To Use Diff-lock	48
How To Activate Diff-lock	48
Stopping Procedure	49

Basic Load Techniques

Travelling With A Load	50
Travelling Without A Load	50

TABLE OF CONTENTS

B. LIFT ASSIST AND PANTOGRAPH

Overview of Lift Assist 98

B1. SAFETY CHECKLIST

Safety Checklist 99

B2. INTRODUCTION

Major Components 100

Safety Decals 101

Instruments & Controls 105

B3. CENTRE OF GRAVITY

Lift Assist Load Moment 108

B4. OPERATING PROCEDURE

Operating Lift Assist & Pantograph 109

B5. MOUNTING PROCEDURE

Mounting Machine 112

B6. MAINTENANCE

Grease Points 113

C. MACHINE WITH 4-WAY STEERING

Overview Of 4-Way Steering 124

C1. SAFETY CHECKLIST

Safety Checklist 125

C2. INTRODUCTION

4-Way Safety Decals 126

Instruments & Controls 128

Dash 4-Way 128

C3 CENTRE OF GRAVITY

Centre Of Gravity- 4-Way 129

C4. OPERATING PROCEDURE

Operating Procedures 131

Changing Steering Modes 132

Lifting And Placing Wide Loads 135

Operating On Inclines 137

Load Supports 140

Points To Remember 141

C5. MOUNTING PROCEDURE

Mounting Machine 142

C6. MAINTENANCE

Grease Points 143

Daily Maintenance 146

C7. SPECIAL PROCEDURES

4-Way Over Ride Procedure 147

SAFETY NOTICES

In this Operator Manual and on the machine there are safety notices. Each notice starts with a signal word and has a specific colour. The meanings of the signal words and colours are given below.

 **DANGER**

(RED) INDICATES AN IMMEDIATE HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, **WILL** RESULT IN DEATH OR SERIOUS INJURY.

 **WARNING**

(ORANGE) INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH IF NOT AVOIDED **COULD** RESULT IN DEATH OR SERIOUS INJURY.

 **CAUTION**

(YELLOW) INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, **MAY** RESULT IN MINOR OR MODERATE INJURY.

INSTRUCTIONS

(GREEN) INDICATES THE INFORMATION IS FOR INSTRUCTION ONLY.

Study This Operator Manual Before Starting The Machine. You must understand and follow the instructions in this operator manual. You must observe all relevant laws and regulations. If you are unsure about anything, ask your Moffett Truck-Mounted Forklift Distributor or supervisor. **Do not guess**, you or others could be killed or seriously injured.

Note: You must be a trained Moffett Truck-Mounted Forklift operator to use this machine.

1. SAFETY INTRODUCTION

Introduction to General Safety

This section of the Operator Manual is intended to REMIND the operator of basic safety requirements when operating industrial machinery. It is not a complete list of hazards that may exist when operating or maintaining the Moffett Truck-Mounted Forklift.

Specific hazards relating to maintenance instructions and operating procedures are detailed in the relevant sections of this operator manual.

Safety First – Yours and Other Peoples

All industrial equipment can be hazardous. When a machine is properly operated and maintained, it is a safe machine to work with. But when it is carelessly operated or poorly maintained it can become a danger to you (the operator) and to others.

In this operator manual and on the machine you will find warning messages. Read and understand them. They tell you of potential hazards and how to avoid them. If you do not fully understand the warning messages, ask your supervisor or Moffett Truck-Mounted Forklift Distributor to explain them.

Safety is not just a matter of responding to the warnings. All the time you are working on or with the machine you must be thinking what hazards there might be and how to avoid them.

Do not work with the machine until you are sure you can control it. Do not start any job until you are sure that you and those around you will be safe. If you are unsure of anything, about the machine or the job, ask someone who knows. Do not assume anything.

1. SAFETY CHECKLIST

General Safety



WARNING:

Operator Manual. You and others can be injured if you operate or maintain the machine without studying this operator manual. Read the safety instructions before operating this machine. If you do not understand anything, ask your Moffett Truck-Mounted Forklift Distributor or supervisor to explain it. Keep this operator manual clean and in good condition. Do not operate the machine with out an operator manual in the cab, or if there is anything on the machine you do not understand.



WARNING:

Clothing. You can be injured if you do not wear proper clothing. Loose clothing can get caught in the machinery. Wear protective clothing to suit the job. Examples of protective clothing are: a hard hat, safety shoes, safety glasses, a well fitting overall, ear protectors and industrial gloves. Keep cuffs fastened. Do not wear a neck tie or scarf. Keep long hair restrained.



WARNING:

Care and Alertness. All the time you are working with or on the machine, take care and stay alert. Always be careful. Always be aware of potential hazards.



WARNING:

Alcohol and Drugs. It is extremely dangerous to operate machinery when under the influence of alcohol or drugs. Do not consume alcoholic drinks or take drugs before or while operating the machine or attachments. Be aware of medicines which can cause drowsiness.



CAUTION:

Regulations. Obey all laws, work site and local regulations which affect you and your machine.

1. SAFETY CHECKLIST

Operational Safety



DANGER:

Capacity. Never exceed the forklift's rated capacity or the machine may become unstable and could cause serious injury or death.



DANGER:

Transport. Do not attempt to transport the Moffett Truck-Mounted Forklift on a truck or trailer that is not equipped with a mounting kit designed and installed to Moffett Truck-Mounted Forklift specifications.



DANGER:

Stabilisers. Never raise the stabilisers when the mast carriage is extended with a load on.



DANGER:

Forks. Do not permit personnel to stand on or ride on the forks as serious bodily injury could result.



DANGER:

Never approach power lines with any part of the forklift as electrocution could result.



WARNING:

When placing a load, always place the load on a firm and level surface. The stabilisers must always be fully lowered before attempting to extend the mast. When lifting a load, the stabilisers must be fully lowered and raised only when the mast is fully retracted. When travelling without a load, the mast should be extended fully.



WARNING:

Decals. If you need eye-glasses for reading, make sure you wear them when reading the safety decals. Decals are strategically placed around the machine to remind you of possible hazards. Do not over-stretch or place yourself in dangerous positions to read the decals. If any decals get damaged or removed contact your supervisor, have them replaced.

1. SAFETY CHECKLIST

Operational Safety (continued)



WARNING:

Decals. Decals on the machine warn you of particular hazards. Each decal is attached close to a part of the machine where there is a possible hazard. Read and make sure you understand the safety message before you work with or any part of the machine. Keep all decals clean and readable. Replace lost or damaged decals. The decals and their attachment points are shown on the following pages. Each decal has a part number printed beside it. Use this number to order a new decal from your Moffett Truck-Mounted Forklift Distributor.



WARNING:

Hydraulic Pressure. The hydraulic tank is pressurized and hydraulic oil may be hot. To avoid injury when removing cap, stop the engine and remove the cap very slowly. This will avoid spillage and prevent injury.



WARNING:

Engine. Never climb aboard or dismount from the machine with engine running.



WARNING:

Vapours. Hot coolant, steam and vapours can severely burn. Stop engine and allow it to cool before removing the radiator cap. When removing the radiator cap, turn it very slowly to allow the pressure to release.



WARNING:

Transport. Do not attempt to transport the Moffett Truck-Mounted Forklift unless you have read the transport section of the manual very carefully!



WARNING:

Seat Belt. If the seat belt does not 'lock' when fastened do not drive the machine. The seat belt assembly must be replaced immediately.

1. SAFETY CHECKLIST

Operational Safety (continued)



WARNING:

Seat Belt.

- Failure to properly inspect & maintain the seat belt can cause serious injury or loss of life in an accident.
- Any time the Moffett Truck-Mounted Forklift is being operated and is involved in an accident replace the whole seatbelt assembly.
- If the seatbelt is worn or damaged it must be replaced.
- The seatbelt must be inspected at least once a year and more often if exposed to harsh conditions.
- If replacement of any part of the seatbelt is required then the entire assembly must be replaced (Retractor and Buckle) with Moffett Engineering Ltd. recommended items from a service provider.



WARNING:

Seat Belt. The operator's enclosure is designed to give you protection in an accident. If you do not wear your seat belt you could be thrown out of the machine and crushed. You must wear a seat belt when using the machine. Fasten the seat belt before starting the machine.



WARNING:

Safety. Always wear your seatbelt when driving the Moffett Truck-Mounted Forklift. The forklift may tip over if operated incorrectly. To protect the operators from the risk of serious injury or death in the event of a tip over, it is best to be held securely in the seat. The seat and seatbelt will help keep you safely with in the operators compartment. In the event of a tip over, **DO NOT JUMP**. Grip the steering wheel, brace your feet, lean away from the direction of tip-over and stay within the operators compartment.



WARNING:

Loose Articles. Do not leave loose articles in the drivers compartment loose articles can fall and strike you, or roll on the floor. You could be knocked unconscious, or the controls could get jammed. If that happens you could loose control of the machine.

1. SAFETY CHECKLIST

Operational Safety (continued)



WARNING:

Engine Damage. Do not use starting fluid or spray as these are highly flammable, corrosive and cause engine damage.



WARNING:

Procedure. Never leave the operators seat without first:

- Facing the machine uphill and turning the rear wheel sideways if stopped on an incline.
- Engage the park brake.
- Lowering the forks to the ground.
- Placing all controls in the neutral position.
- Stopping the engine.
- Remove the key.



WARNING:

Machine Condition. A defective machine can injure you or others. Do not operate a machine which is defective or has missing parts. Make sure the maintenance procedures in this operator manual are completed before using the machine.



WARNING:

Visibility. Accidents can be caused by working in poor visibility. Use the work lights on the machine to improve visibility. Do not operate the machine if you cannot see properly.



WARNING:

Loading. Before attempting to load a truck or trailer, chock the wheels of the truck/trailer to prevent it moving. Always lower the stabilisers fully before attempting to pick-up from a truck or trailer.



WARNING:

Practice. You or others can be killed or seriously injured if you do unfamiliar operations with out first practicing them. Practice away from the work site on a clear area. Keep other people away. Do not perform new operations until you can do them safely.

1. SAFETY CHECKLIST

Operational Safety (continued)



WARNING:

Controls. You or others can be killed or seriously injured if you control the machine from outside the drivers compartment. Operate the control levers only when you are correctly seated inside the driver's compartment with seatbelt fastened.



WARNING:

Controls. If the Forward/Reverse pedal does not return to the neutral position, do NOT use the machine and contact your supervisor.



WARNING:

Passengers. Passengers in or on the machine can cause accidents. The Moffett Truck-Mounted Forklift is a one man machine. Do not carry passengers.



CAUTION:

Hydraulic Pressure. It is important to release the hydraulic pressure as stated so that the weight of the Moffett Truck-Mounted Forklift is carried by the mounting kit and transport chains and NOT by the mast. Otherwise damage will result from the fork lift's weight resting on the mast.



CAUTION:

Diff-lock. Use the diff-lock only while travelling in a straight line.



CAUTION:

Rear Bumper. The rear bumper must be folded back out to full length and the locking pin and lynch pin fitted when the forklift is not being transported or removed for the purposes of loading or unloading.



CAUTION:

Hydraulic Function. Never continue to operate a hydraulic function lever after the function has reached the end of its travel.

1. SAFETY CHECKLIST

Operational Safety (continued)



CAUTION:

Safe Operation.

If something comes loose, breaks or fails to operate:

- Stop.
- Apply the park brake.
- Shut down the engine.
- Get it repaired.



CAUTION:

Wide Loads. When carrying wide or tall loads your visibility may be blocked by the load. It may be safer to travel in reverse when moving with such loads. You may require a signal person or “spotter” to guide you. Do not drive uphill in reverse. If the street lights are blocked by the load the work lights must be used to improve visibility and ensure you are seen by other road users.



CAUTION:

Mounting. When truck mounting do not use the pantograph device. Mount the machine as outlined in the normal mounting procedure as explained in section B5.



CAUTION:

Temperature. Always turn off the engine and allow it to cool before checking:

- Engine coolant level
- Engine oil level
- Hydraulic oil level

1. SAFETY CHECKLIST

Maintenance Safety



WARNING:

Raised Attachments. Raised attachments can fall and injure you. Do not walk or work under raised attachments unless they are safely blocked.



WARNING:

Raised Machine. NEVER position yourself or any part of your body under a raised machine which is not properly supported. If the machine moves unexpectedly you could become trapped and suffer serious injury or be killed.



WARNING:

Soft Ground. A machine can sink into soft ground. Never work under a machine on soft ground.



WARNING:

Lifting Equipment. If you are using lifting equipment to lift or repair your machine, you can be injured. Make sure that the lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.



WARNING:

Repairs. Do not try to do any repairs or any other type of maintenance work you do not understand. Moffett Truck-Mounted Forklift Engineers have been trained in all aspects of the Truck-Mounted Forklift.



WARNING:

Hydraulic Fluid. Fine jets of hydraulic fluid at high pressure can penetrate the skin. Do not use your fingers for hydraulic fluid leaks. Do not put your face close to suspected leaks. Hold a piece of cardboard close to the suspected leaks and then inspect the cardboard for signs of hydraulic fluid. If hydraulic fluid penetrates your skin, seek medical attention immediately.



WARNING:

Hydraulic Pressure. Hydraulic fluid at pressure can injure you. Make the machine safe before connecting or disconnecting couplings; lower the payload to the ground, stop the engine then operate the hydraulic controls a few more times to vent residual hydraulic pressure from the system.

1. SAFETY CHECKLIST

Maintenance Safety (continued)



WARNING:

Hydraulic Hoses. Damaged hoses can cause fatal accidents. Inspect the hoses regularly for:

- Damaged end fittings
- Chafed outer covers
- Ballooned outer covers
- Kinked or crushed hoses
- Embedded or armoring in outer covers
- Displaced end fittings.



WARNING:

Metal Splinters. You can be injured by flying metal splinters when driving pins in or out. Use a soft faced hammer or drift to remove and fit metal pins. Always wear safety glasses.



WARNING:

'O' Rings, Seals and Gaskets. Badly fitted, damaged or rotted 'O' rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed, unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.



WARNING:

Electrical Circuits. Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

Do not disconnect the battery when the machine is running otherwise the electrical circuits may be damaged.



WARNING:

Communications. Bad communications can cause accidents. If two or more people are working on a machine, make sure each knows what the others are doing. Before starting the engine make sure others are clear of the danger areas; examples of the danger areas are: the rotating blades and belt on the engine, the attachments and linkages, and anywhere beneath or behind the machine. People can be killed or injured if these precautions are not taken.

1. SAFETY CHECKLIST

Maintenance Safety (continued)



CAUTION:

Cleaning. Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.



CAUTION:

Machine Modifications. This machine is manufactured in compliance with legislative and other requirements. It should not be altered in any way which could affect or invalidate any of the requirements. For advice contact your Moffett Truck-Mounted Forklift Distributor



CAUTION:

Welding. Before carrying out any welding on the machine, disconnect the battery and alternator to protect the circuits and components.

The battery must still be disconnected even if a battery isolator is fitted.

Make sure the welding path is kept as short as possible. This prevents high currents being induced into the machine frame or wiring harness.

2. INTRODUCTION

About This Operator Manual

Machine Models.

This operator manual provides information for the Moving Mast Range of Moffett Truck-Mounted Forklifts.

Using This Operator Manual.

The illustrations in the operator manual are for guidance only. Where machines differ, the text and/or illustration will specify.

This operator manual is arranged to give a good understanding of the machine and its safe operation. It also contains maintenance information and specification data. Read this operator manual from front to back before using the machine for the first time. Particular attention must be given to all the safety aspects of operating and maintaining the machine.

General warnings in this chapter are repeated throughout this manual as well as specific warnings. Read all the safety statements regularly, so you don't forget them. Remember that the best operators are the safest operators.

Finally, treat this operator manual as part of the machine. Keep it clean and in good condition and ensure it is always located in the operator manual box on the back of the seat.

If there anything you are unsure about ask your supervisor or Moffett Truck-Mounted Forklift Distributor. Do not guess, you or others could be killed or seriously injured.

The manufacture's policy is one of continuous improvement. The right to change the specification of the machine without notice is reserved.

No responsibility will be accepted for discrepancies which may occur between the specifications of the machine and the descriptions contained in this publication.

Using The Machine.

To use the Moffett Truck-Mounted Forklift efficiently and safely you must know the machine, and be trained and authorized to use it.


This Operator Manual is intended to familiarise you on the machine, its controls and its safe operation. It is not intended or suitable for use as a training manual for an inexperienced operator.

2. INTRODUCTION

The Moffett Truck-Mounted Forklift


Machine Description.

The Moffett Truck-Mounted Forklift is a three wheeled, non-counterbalanced forklift capable of being transported on the rear of a truck or trailer. Its short turning radius and rear wheel steer make it extremely manoeuvrable in confined spaces. The forklift is equipped with a mast that can move in and out on a mast carriage. The mast is fitted with a double acting lift cylinder which means a load can be lifted on the forks by the full bore side of the cylinder but also that the machine can be lifted for truck mounting using the rod side of the cylinder.





Concept

Unlike a conventional forklift the Truck Mounted Forklift does not have a counterweight at the rear, instead it uses its own weight to counter the load. Normally the front fulcrum for the machine is located under the front tyre. By lowering stabilisers this fulcrum is moved forward and with the mast extended this allows the forklifts weight to counter the capacity to be lifted. Once the load has been picked then the mast is retracted bringing the load into the frame of the forklift. At this stage the stabilisers can be raised and the machine can travel with the load.



2. INTRODUCTION

Major Components



1. Forks
2. Stabilisers
3. Fork Face
4. Fork Carriage
5. Road Lights
6. Lift Chains
7. Mast
8. Hood
9. Hydraulic Controls
10. Steering Wheel
11. Beacon
12. Overhead Guard
13. Operators Compartment
14. Seat
15. Side Guard
16. Work Light
17. Seat Belt
18. Grab Handles x2
19. Foot Pedals
20. Steps
21. Serial plate

2. INTRODUCTION

Identifying Your Machine

Serial Plate: This is located in the driver's compartment and it gives the following information:

Type: This is the machine model. i.e. M5 (example below).

Serial No: This is a unique number given to all machines.

Its 7 digit configuration is also stamped into the machine chassis and is as follows e.g.:

E 24 054 5

E	Year of Manufacture.
24	Week Number.
054	Sequential Number.
5	Machine Model.

Rated Capacity: The rated lifting capacity of the machine with the mast carriage fully extended and stabilisers down.

Load Centre: Load centre of rated capacity.

Unladen Weight: The gross weight of the machine.

Date: The date of manufacture of the machine.

266130

TYPE	<input type="text"/>
SERIAL No.	<input type="text"/>
RATED CAPACITY	<input type="text"/> Kg
LOAD CENTRE	<input type="text"/> mm
UNLADEN WEIGHT	<input type="text"/> Kg
DATE :	<input type="text"/>

____MANUFACTURED BY____

CE MOFFETT ENGINEERING LTD.
ARDEE ROAD, DUNDALK, Co. LOUTH, IRELAND.
TEL: + 353 42 59500
FAX: + 353 42 59590

2. INTRODUCTION

Safety Decals

General



If you need eye-glasses for reading, make sure you wear them when reading the safety decals. Decals are strategically placed around the machine to remind you of possible hazards. Do not over-stretch or place yourself in dangerous positions to read the decals.



Decals on the machine warn you of particular hazards. Each decal is attached close to a part of the machine where there is a possible hazard. Read and make sure you understand the safety message before you work with or around any part of the machine.


Keep all decals clean and readable. Replace lost or damaged decals. The decals and their attachment points are shown on the following pages. Each decal has a part number printed beside it. Use this number to order a new decal from your Moffett Truck-Mounted Forklift Distributor.

Part No. 517.100.0077




WARNING


Note: Authorized and Trained Operators only allowed on machine !



Always close the Side Guard before operating machine




Always fasten your Seat Belt before operating machine



Read and understand your manual located on rear of the seat

517.100.0077





Note:
The Forklift will not drive unless seatbelt is engaged

2. INTRODUCTION

Safety Decals (continued)



Part No. 517.100.0103



Note: Lower and Go only works when ignition key is in the off position.

OR

Part No. 517.056.0115





Safety Decals (continued)



DANGER:

Do not permit personnel to stand on or ride on the forks or load as serious bodily injury could result.

Part No. Usa001



2. INTRODUCTION

Part No. Eng002

SAFETY INSTRUCTIONS

DO NOT OPERATE THIS MACHINE UNLESS:

- You have read and understand the safety and operating instructions contained in the operator manual and viewed the Moffett Truck-Mounted Forklift Operator Training Video.
- You have been trained in the safe operation of the Moffett Truck-Mounted Forklift.
- You have checked your machine and all functions are operating correctly.

WHEN TRAVELLING WITHOUT A LOAD:

- Keep the mast fully forward and as low as possible.
- Centre the fork carriage using the side-shift function.

WHEN TRAVELLING WITH A LOAD:


- Keep the forks fully retracted and the load as low as possible.
- Make all turning manoeuvres slowly and carefully. Do not stop suddenly.
- Travel with the load side-shifted to the centre position.

WHEN TRAVELLING ON INCLINES:

- Travel directly up or down, do not travel across an incline.
- Keep the forks facing uphill at all times.
- Engage the diff-lock if operating on slippery slopes.
- Keep the load as low as possible. Do not elevate the load.

WHEN LIFTING A LOAD:

- Check that the stabilizers are fully lowered on a firm and stable surface.
- Do not raise the stabilizers unless the forks are fully retracted.



2. INTRODUCTION







Safety Decals (continued)

Part No.517.100.0085

MOUNTING INSTRUCTIONS







TO MOUNT THE MACHINE ON A TRUCK/TRAILER

- Approach the truck/trailer with the most extended forks fully.
- Locate the forks between the fork supports.
- Drive into truck/trailer fully.
- Tilt the most rearward fork to raise the rear wheel.
- Raise the machine by lowering the forks.

TO DISMOUNT THE MACHINE FROM A TRUCK/TRAILER

- Disconnect the suze cable.
- Start the engine.
- Raise the machine and tilt the most rearward.
- Turn off the engine.
- Remove the transport chains.
- Fasten the seat belt.
- Extend the most slowly forward to move the forklift backwards out of the mounting kit.
- Raise the forks to lower the forklift to the ground.

NOTE:

- ALWAYS USE THE 3-POINT CONTACT METHOD WHEN ENTERING OR EXITING THE OPERATOR STATION.
- ENSURE THE PARKING BRAKE IS DISENGAGED IN TRANSPORT.
- ALWAYS CLOSE THE SIDE GUARD AFTER EXITING THE OPERATOR STATION.
- ENSURE THE FOLDING DOT BUMPER IS EXTENDED AND PINNED ON BOTH SIDES WHEN THE MACHINE IS NOT MOUNTED.



517.100.0085

Part No.
517.100.0141

IMPORTANT

HYDRAULIC OIL ONLY

517.100.0141



 **WARNING**

Pressurized hydraulic oil reservoir. Turn off engine. Remove cap slowly to release pressure and avoid spillage.

ENG003

Part No. Eng003



WARNING:


The hydraulic tank is pressurized and hydraulic oil may be hot. To avoid injury when removing cap, stop the engine and remove the cap very slowly. This will avoid spillage and prevent injury.

2. INTRODUCTION



Safety Decals (continued)

Swing Up Type Door

Part No. 517.120.0000





Part No. 517.120.0001



2. INTRODUCTION

Safety Decals (continued)

Part No. Eng004



WARNING:

Hot coolant, steam and vapours can severely burn. Stop engine and allow it to cool before removing the radiator cap. When removing the radiator cap, turn it very slowly to allow the pressure to release.

2. INTRODUCTION

Safety Decals (continued)


Part No. Eng010



Part No. USA018




Note: This machine is fitted with an interlocking seatbelt. The machine will not drive unless the seatbelt is engaged.





2. INTRODUCTION

Safety Decals (continued)

Part No. ENG019



Part No. ENG011





Note: Location of pinch points
decals P.N. – ENG011 on
stabilisers and tilt cylinders

2. INTRODUCTION

Safety Decals (continued)

Part No. Eng007



2. INTRODUCTION

Safety Decals (continued)



Note: When replacing decals always ensure correct part number is supplied

Part No. 517.055.0006

Part No. 517.120.0003


**IMPORTANT
ENGAGE SEATBELT
TO DRIVE MACHINE**

517.055.0006



2. INTRODUCTION

Safety Decals (continued)




2. INTRODUCTION

Instruments and Controls

The Moffett Truck-Mounted Forklift is provided with a set of controls to enable you to operate the machine safely and efficiently.


The instruments and controls are in the following groups:

- A** Forward/Reverse Pedal
- B** Throttle
- C** Side Guard
- D** Starter Reset
- E** Hour Meter
- F** Dash Panel
- G** Steering Wheel
- H** Hydraulic Controls
- I** Switches
- J** Ignition Switch
- K** Warning Lights
- L** Park Brake
- M** Manual Box













2. INTRODUCTION

Instruments And Controls (continued)



Note: 4-Way dash configuration section C2

-  **Engine Preheater**
-  **Air Filter Blockage**
-  **Battery (No Charge)**
-  **Engine Oil Pressure Low**
-  **Park Brake Engaged**
-  **Indicators**
-  **Horn**
-  **Difflock Engaged**
-  **Main Beam**
-  **Work Lights**

2. INTRODUCTION

Instruments And Controls (continued)

Ignition Switch / Pre Heater

When turned clockwise, the ignition switch sends electrical power to the engine starter motor and glow plugs, thus starting the machine.

Park Brake

The park brake should be engaged when the forklift is parked. It should **NOT** be engaged when the forklift is in transport on the rear of a truck or trailer.

Note: If Seatbelt is not connected then Park Brake is automatically applied.

Flashing Beacon

The Moffett Truck-Mounted Forklift is fitted with a flashing beacon. The beacon is activated when the ignition is turned to the ON position. If the beacon fails to work when the machine is turned ON, do not operate the machine. Contact your supervisor.

Diff-Lock

When activated this transfers equal flow to all 3 wheels to improve traction.

Horn

The horn is used to alert people of your manoeuvres.

Hour Meter

Indicates the engine operating hours.

Indicators

The indicator switch is located on the dash panel. Pushing the top of the switch activates the left indicators pushing the bottom of the switch activates the right indicators. Always turn off the indicators once you have finished a manoeuvre.

Street Lights

Street lights should be used when travelling on a public highway.

Note: Dip beam should always be used when approaching other users of the highway.

Work Lights

Work lights should be used on site when visibility is poor. They may also be used to improve visibility if the road lights are blocked while carrying a load.

Water Gauge

The water gauge is used to display the operating temperature of the engine.

Fuel Gauge

The fuel gauge indicates the amount of fuel in the fuel tank.

Starter Reset

The starter reset, is a thermostatic trip switch that prevents the starter motor from over heating. If this trips wait 30 seconds push the reset button and retry starting the machine.

2. INTRODUCTION

Transmission Controls

The machine can be fitted with the following drive control options:

1. **“STD” Pump** – Control comprises :
Hydraulic Foot operated Forward / Reverse Pedal
Foot operated Accelerator pedal
2. **“Anti Stall” Pump** – Control comprises:
Hydraulic Foot operated Forward / Reverse Pedal
Foot operated Accelerator pedal
3. **“Automotive” Pump** – Control comprises:
Column Shift Forward / Reverse lever
Foot operated “inching/brake” pedal
Foot operated Accelerator pedal

1. STD Pump - Hydraulic Foot-Pedal Control

With foot-pedal control, the Moffett Truck-Mounted Forklift is equipped with two foot pedals. The right pedal is the accelerator pedal which controls the engine RPM (speed). The left pedal is the hydraulic pedal, which controls the forward and reverse movement.

Accelerator Pedal – Engine RPM

This pedal is pressed down to increase engine RPM. It should be used to keep the engine at a constant RPM and should not be used to adjust the travel speed of the machine. The engine RPM also affects the speed of the hydraulic functions.

Forward/Reverse Pedal – Travelling Speed

This pedal controls the forward and reverse movement of the machine. The machine will not move if you do not press the hydraulic pedal. Depress the pedal(toe) forward to move the machine forward. Depress the pedal(heel) back to move the machine in reverse. By returning the pedal to mid-point (neutral) the machine will stop. This pedal is also used to control the speed of the machines movement. The further the pedal is pressed in either direction, the faster the machine will travel. When travelling on gradients or on rough terrain, forward/reverse pedal movement should be reduced and engine RPM increased.




WARNING:

If forward/reverse pedal does not return to neutral do not use the machine and contact your supervisor.

Forward/Reverse Pedal

Accelerator Pedal



2. INTRODUCTION

Transmission Controls (continued)

2. Anti-Stall Pump – Hydraulic Foot-Pedal Control.

The Anti Stall hydrostatic drive pump greatly enhances smooth, slow travel which is important when operating with large or long loads.

When driving the operator controls the speed and torque using the accelerator pedal only, while keeping the forward/reverse pedal fully depressed in the direction of travel.


This capability is due to the pump being able to sense the engine load and self-adjust to the conditions accordingly (similar to an automatic transmission in an automobile where you do not need to shift up or down).

3. Automotive Pump – Column Shift Control.

With automotive control the Moffett Truck-Mounted Forklift is equipped with two foot pedals and column mounted forward/reverse hand lever. The right pedal is the accelerator pedal which controls both engine RPM and speed of travel. The left pedal is the “inching/brake” pedal which is used to stop the machine or move the machine slowly.

Note: The engine will not start unless the forward/reverse lever is in the neutral position while turning the key.

Forward / Reverse Lever



Inching / Brake Pedal

Accelerator Pedal

The accelerator pedal is used to control both engine RPM and speed of travel of the machine. The accelerator pedal regulates RPM but will not move the machine until the forward/reverse hand lever is activated.

2. INTRODUCTION

Transmission Controls (continued)

Operation

TO MOVE THE MACHINE FORWARD – Move the forward/reverse lever to the forward position and depress the accelerator pedal – the machine will move forward.

TO MOVE THE MACHINE BACKWARD – Move the forward/reverse lever to the backwards position and depress the accelerator pedal – the machine will move backwards.

TO STOP THE MACHINE – Release the accelerator pedal and the machine will stop. Alternatively, depressing the “inching/brake” pedal fully will stop the machine more quickly.

Note: The higher the RPM the faster the machine will travel. When climbing a gradient or hill, the operator should keep the accelerator pedal depressed because the speed of the machine will reduce as the gradient increases.

The engine will not start unless the forward/reverse lever is in the neutral position while turning the key. The machine will not drive unless the interlocking seatbelt is connected.

“Inching/Brake” Pedal

This pedal has two functions;-

1. ‘Brake’ pedal – to stop the machine quickly.
2. ‘Inching’ pedal –to allow small controlled movements of the machine regardless of how high the engine speed is

The inching/brake pedal allows the operator to control the travel speed of the Moffett Truck-Mounted Forklift while keeping engine speed up to raise and tilt the fork carriage. The operator should keep the forklift RPM high if he wants to raise the boom quickly.

To stop the forward movement of the Moffett Truck-Mounted Forklift while maintaining high engine RPM, depress the inch pedal fully and the machine will stop moving. By releasing the “inching/brake” pedal slightly, the machine will move slowly. To stop its movement depress the pedal fully again. By gradually releasing the “inching/brake” pedal, the machine will gradually increase its travel speed.

Because of its ability to stop the machine, the “inching/brake” pedal can be used as a brake pedal. By fully depressing the “inching/brake” pedal the machine will stop, irrespective of the engine speed.

This pedal is also referred to as a “creeper/brake” pedal for its ability to move the machine slowly even with high engine RPM. This permits the precise, controlled creeping movements necessary when lifting or placing a load.

2. INTRODUCTION

Mast and Carriage Controls

The Moffett Truck-Mounted Forklift is equipped with hydraulic levers to control movement of the mast, forks and stabilisers. **STUDY THE VALVE BANK DECAL FOR YOUR MOFFETT TRUCK-MOUNTED FORKLIFT BEFORE OPERATING THE MACHINE.**

A. Forks – Raise and Lower:

This lever raises and lowers the forks. Forward movement of the lever will lower the forks down. Backward movement of the lever will raise the forks up.

B. Mast – Extend and Retract:

This lever moves the mast forwards and backwards. Forward movement of the lever extends the mast forward, away from the operator (out). Backward movement of the lever retracts the mast backward towards the operator (in). When placing a load, the mast should be extended only when the stabilisers are fully lowered.

C. Tilt Mast – Forward and Back: This lever tilts the mast forwards and backwards. Forward movement of the lever tilts the mast forward (Forks Down). Backward movement of the lever tilts the mast rearward (Forks Up). Loads should normally be transported with the mast tilted back.

D. Side-Shift – Left and Right:

This lever moves the mast to the right or left. Forward movement of the lever shifts the mast to the left. Backward movement of the lever shifts the mast to the right.


E. Stabilisers – Lower and Raise:

This lever raises and lowers the stabilising legs. When placing a load, the stabilisers must always be fully lowered before moving the mast forward. Forward movement of the lever will lower the stabilisers (down). Backwards movement of the lever raises the stabilisers (up). When lifting a load, never raise the stabilisers until the mast is fully retracted.

Note: When the ground is not firm enough to support the stabilisers extra support plates must be used of sufficient size and strength to ensure they do not sink, bend or buckle during operation. A second person may be required to check the support plates. If at any time the stabilisers or pads show sign of sinking the procedure must be stopped immediately, the mast carriage fully retracted and an alternative location found. If in doubt prior to or during an operation on loose, uneven or soft surfaces, stop. Always consider safety first.

2. INTRODUCTION

Mast and Carriage Controls (continued)



A

B

C

D

E

3. CENTRE OF GRAVITY

Basic Principles


Introduction

Make the right start – know the load capacities of your Moffett Truck-Mounted Forklift. The rated capacity of the machine is the weight that the machine is capable of lifting under safe operating conditions. Remember that type of terrain or ground conditions can reduce the amount you should lift.

The shape of the load will also affect the lift capacity of the machine. Inspect the load you intend to lift. Make sure that you know the weight of the load. If the weight is not marked or shown on the load, check the weight of the load with your supervisor or have it weighed. If it is too heavy split the load and restack it. It is common for a large capacity conventional forklift to be used when loading trucks or trailers in a yard. Do not expect the Moffett Truck-Mounted Forklift to lift the load just because a conventional yard forklift initially loaded it.

Remember that, if attachments are used other than the standard pallet, lumber, brick or block forks which are normally furnished with the Moffett Truck-Mounted Forklift, such attachments will reduce the lifting capacity and affect other machine handling characteristics.

With the Moffett Truck-Mounted Forklift rated capacity is based on a cube measuring 1200mm in all three dimensions with the centre of gravity in the centre of this cube. This is known as a 600mm-load centre. If the dimensions of the load increase or the position of the centre of gravity or load moves forward, the lifting capacity of the machine will be reduced.



3. CENTRE OF GRAVITY

Basic Principles (continued)

Introduction

Refer to the load chart in the operator's compartment of your machine. Study it carefully and make sure you understand it before attempting to operate the Moffett Truck-Mounted Forklift. Remember that the weight to be lifted and the height it is lifted to must not exceed the rated capacity of your machine.

The load capacity chart relating to your particular model gives details of what your machine can lift with a 600mm load centre under the following conditions;


- 1) Stabilisers raised and mast fully extended forward.
- 2) Stabilisers fully lowered and mast fully extended forward.
- 3) Stabilisers raised and mast fully retracted backwards.

The following sample Load Capacity Chart illustrates the rated stacking capacity of a M5 30.3 Moffett Truck-Mounted Forklift equipped with standard forks.


Note:

1. The load capacity may vary depending on attachments used. Consult the load chart on your machine for actual rated capacity.

2. Other Moffett Truck-Mounted Forklift models have different load capacities. Refer to the load capacity chart on your machine.
3. If the existing load capacity chart becomes damaged, lost or illegible, replace the load capacity chart. Load capacity charts are available from your dealer.



SAMPLE LOAD CHART



Green Area Indicates Safe Lifting Range



DANGER:

Never exceed the forklifts rated capacity or the machine may become unstable and could cause serious injury or death.

3. CENTRE OF GRAVITY

Basic Principles (continued)


Comparison Between A Conventional Forklift And A Moffett Truck-Mounted Forklift

Conventional Forklift

A **conventional forklift** is designed to lift and carry the load in front of the wheels. The load remains in this position during transit. The conventional forklift is able to lift the load in this position because it has a large rear-mounted counterweight to counterbalance the load. A conventional forklift is known as a counterbalanced forklift.

With a conventional counterbalanced forklift, the position of the load remains stationary relative to the front wheels. The mast does not move forward and backward like a Moffett Truck-Mounted Forklift. The front wheels of a conventional counterbalanced forklift are the points of pivot known as the fulcrum point.

If the load exceeds the rated capacity of the forklift, the weight of the load may overcome the counterbalance effect and cause the load and the forklift to tip forward.



3. CENTRE OF GRAVITY

Basic Principles (continued)

Comparison Between A Conventional Forklift And A Moffett Truck-Mounted Forklift



Moffett Truck-Mounted Forklift

An important feature of the Moffett Truck-Mounted Forklift is that it is light enough to be transported on the rear of the truck or trailer. Unlike a conventional forklift, it does not have a rear-mounted counterweight. The Moffett Truck-Mounted Forklift has a reach mast and hydraulic stabilisers. With the stabilisers raised the fulcrum point is at the front wheel.

When the stabilisers are fully lowered, the fulcrum point moves forward to the point of contact between the stabilisers and the ground.

This action increases the counterbalance effect and enables the Moffett Truck-Mounted Forklift to lift the rated capacity with the mast in the forward position without the need for a large counterweight.

When placing a load, the stabilisers must always be fully lowered before the mast is extended. When lifting a load, the stabilisers must be fully lowered and raised only after the mast is retracted fully. When carrying a load the mast must always be retracted fully.



4. OPERATING PROCEDURES

Using the Machine

Before Using The Machine

Before you begin to operate the Moffett Forklift you must have completed the Moffett training program, understand and follow all information in this manual. Each day you operate the machine, complete all of the Daily Inspection Checks as detailed in the MAINTENANCE section of this operator manual.


Entering Operator's Compartment

Always climb aboard the vehicle properly. Use "three point contact" method and face the machine when you climb aboard or dismount the Moffett Truck-Mounted Forklift "three point contact" means that 3 out of 4 arms and legs are in contact with the machine at all times during mount and dismount. Clean your shoes and wipe your hands before climbing on. Use the overhead guard, grab-handle and step when climbing on or off. Do not use the side guard as a grab-handle. Make sure the side guard is secured before mounting or dismounting. Never climb aboard or dismount when the engine is running or when the machine is moving. Never use the control levers or the steering wheel as a hand-hold when climbing on or off the Moffett Truck-Mounted Forklift.



WARNING:

Never climb aboard or dismount the machine with engine running.



4. OPERATING PROCEDURES

Over Head Guard


The Over Head Guard (OHG) is designed to give you protection in an accident. You must always wear your seat belt and close the side guard, you could be thrown about inside the drivers compartment, or thrown out of the machine and crushed. Always fasten the seat belt and close side guard before starting the machine.

If the machine is involved in an accident, hold onto the steering wheel tightly, brace your feet and lean away from impact. When the machine comes to a rest, switch the starter key to the OFF position, remove the seat belt and exit the machine.

Never carry out any unauthorized alterations to the over head guard, eg. Lowering the roof height, drilling, welding on brackets for a fire extinguisher, radio aerial or other equipment, without first having discussed the alteration with engineering personnel at Moffett Engineering Ltd. Engineering Department.

Any modification can adversely affect the structural integrity of the over head guard and could cause the over head guard to fail in the event of an accident.

Location of Overhead Guard Conformity Plate



4. OPERATING PROCEDURES


Rollover



DANGER:

Any machine that is used to lift and move loads may tip over if not operated correctly. No matter how experienced the operator is, accidents can still happen if the operator does not remain vigilant. Always be aware of the potential danger involved when using the Moffett Truck-Mounted Forklift. Be aware of what action you MUST take if the machine starts to tip or roll over.

**DO NOT ATTEMPT TO JUMP OUT – STAY IN THE MACHINE
HOLD TIGHTLY ONTO THE STEERING WHEEL – BRACE YOUR FEET
AND LEAN AWAY FROM IMPACT**



WHEN THE MACHINE HAS COME TO REST – EXIT VIA SAFEST ROUTE

4. OPERATING PROCEDURES

Using the Machine

Adjusting the Seat

The operator's seat can be adjusted for your comfort. A correctly adjusted seat will reduce operator fatigue. Position the seat so that you can comfortably reach the machine controls. Make sure that you can depress the foot controls fully with you back against the seat back.

Fasten the Seat Belt and Close the Side Guard.



WARNING:


Always wear your seatbelt when driving the Moffett Truck Mounted Forklift. The Forklift may tip over if operated incorrectly. To protect the operator from risk of serious injury or death in the event of a tip over, it is best to be held securely in the seat. The seat and seatbelt will help to keep you safely within the operator's compartment. In the event of a tip over **DO NOT JUMP** grip the steering wheel, brace your feet and lean away from direction of tip over staying within the operator's compartment.



WARNING:

When checking the seat belt, if it does not lock, do not drive the machine. The seat belt assembly must be replaced immediately.

1. Sit correctly in the seat. Make sure the belt is not twisted. Push the male end **C** into the buckle **A** until it latches.
2. Make sure the seat belt is across your hips and not over your stomach.
3. Press button **B** to release the seat belt.



Note: The Forklift will not drive unless the seat belt is connected across the operators hips.

4. OPERATING PROCEDURES

Starting The Engine

Start Safely

Adjust the seat, fasten the seat belt and close the side guard. Ensure all operating controls including the forward/reverse pedal, and hydraulic levers are in the neutral position before starting. Use the engine heater to preheat the engine. Alert people in the area before starting the machine. When starting your equipment in an enclosed space, make sure that there is adequate ventilation.




WARNING:

Do not use starting fluid or spray as these are highly flammable, corrosive and cause engine damage.

Insert the key in the ignition. Turn the key clockwise to the "preheat" position and hold for approximately 6 seconds or until the preheat light goes out. Depress the accelerator pedal half way and turn the key until the starter engages and the engine starts. Do not engage the starter for any more than 10 seconds. Release the key and it automatically returns to the "on" position. If the engine fails to start turn off the key for 30 seconds and repeat the starting procedure.

Note: If the engine is cranked excessively a "thermal switch" may cut in to prevent the starter motor from over heating. If this occurs wait 30 seconds push the reset button and retry starting the machine.



After starting, check that all red instrument panel warnings lights have gone out and that all gauges are functioning properly. If all red warning lights have not gone out, stop the engine immediately. Do not attempt to operate the Moffett Truck-Mounted Forklift with a warning light on, as serious damage could occur to the engine.

4. OPERATING PROCEDURES

Driving Techniques

Driving Forward

When driving a loaded machine forward, always accelerate smoothly and slowly. If you accelerate quickly or with jerky movements, the load could fall or the machine may become unstable. Keep the mast retracted and the load as low as possible. Always drive the machine slowly to avoid the risk of having to brake sharply. Always make sure your route is clear of obstructions and take care to avoid endangering pedestrians.

Reversing

When reversing, turn your head to face the direction of travel or get assistance of a reliable person to guide you. Always make sure your route is clear of obstructions and take care to avoid endangering pedestrians.

Always ensure the reverse beeper is functioning correctly and can be heard clearly by people around the machine.

Turning

The machine may become unstable if you turn too quickly or too sharply. Always turn slowly and smoothly. If you turn too quickly or too sharply, the load could fall off or the machine could become unstable. Keep the load as low as possible.

The Moffett Truck-Mounted Forklift steers from the rear and can turn on a very tight radius. Tail swing and fork swing must be considered when turning. Always turn slowly and check for clearances at the fork tips and both rear corners of the forklift. When the machine turns, it rotates around either the right front or the left front wheel depending on the direction of the turn. Therefore, the operator must be aware of the unequal turning arcs relative to the offset seating position. When travelling empty with the mast and forks extended, fork swing is greatly increased.

Parking

Always park the Moffett-Truck Mounted Forklift in a designated safe area. Apply the park brake. Lower the forks fully to the ground. Neutralise all controls. Switch off the ignition and remove the key. Chock the wheels if the vehicle is on uneven ground.

If parking on an incline, point the machine uphill, chock the front wheels and turn the rear wheel across the incline.

Note: For machines equipped with a brake on the rear hub, it is recommended that the stabilisers be lowered when parking the machine on incline.

4. OPERATING PROCEDURES

Driving Techniques (continued)


Operating On Inclines

The Moffett Truck-Mounted Forklift is intended for use on firm, flat and stable surfaces. AVOID slopes and uneven or unstable surfaces where possible. However, when job site conditions involve slopes, inclines or rough terrain, you must take additional care when operating the machine.

- Do not travel across an incline.
- ALWAYS APPROACH AN INCLINE STRAIGHT ON AND TRAVEL UP AND DOWN THE INCLINE.
- Keep the forks pointed uphill.
- Always travel in reverse when descending an incline.
- Do not turn on an incline.
- Never stop or start suddenly.
- Operate all controls smoothly.
- Watch out for potholes or other obstacles that could affect the stability of the machine.
- Drive slowly over rough terrain.
- Where necessary, engage the diff-lock and travel slowly for additional traction.
- Do not attempt to reverse down an incline that you think you would have difficulty driving up.

Operating with a load:

- Travel with the load and forks facing uphill.
- Make allowances for a reduction in both stability and lift capacity when operating on inclines.
- Always take great care when transporting wide loads on any incline. Carry the load as low as possible above the frame of the machine.
- Keep the mast fully retracted.




4. OPERATING PROCEDURES

Driving Techniques (continued)

Operating without a load

- Extend the mast fully and point the forks uphill on an incline.
- Keep the forks as low as possible.
- Remember that your safety is most important and should not be compromised. You are the operator and you are in control of your safety. Do not take any chances!

Always wear your seat belt when driving the Moffett Truck-Mounted Forklift. The machine may tip over if operated incorrectly. In the event of a tip over, it is best to be held securely in the seat, to protect you from the risk of serious injury or death.



WARNING:

Always wear your seatbelt when driving the Moffett Truck-Mounted Forklift. The forklift may tip over if operated incorrectly. To protect the operators from the risk of serious injury or death in the event of a tip over, it is best to be held securely in the seat. The seat and seatbelt will help keep you safely within the operators compartment. In the event of a tip over, DO NOT JUMP. Grip the steering wheel, brace your feet, lean away from the direction of tip-over and stay within the operators compartment.

4. OPERATING PROCEDURES

Diff-Lock

Operation of Diff-Lock

Under normal driving conditions the Moffett Truck-Mounted Forklift operates in all-wheel drive. However, in the event of one or more wheels losing grip, the machine may lose traction, stop or skid. By engaging the diff-lock, you will get equal positive drive to all three wheels.

When to use Diff-lock

- If one or more wheels lose traction while travelling through soft or slippery ground conditions.
- To maintain traction while travelling on slopes or inclines.
- To improve braking and traction when reversing downhill.

To avoid damage to the hydraulic system:

- Do not engage the diff-lock when the machine is moving.
- Do not use the diff-lock where traction is good.
- Do not use the diff-lock when turning corners.



CAUTION:

Use the diff-lock only while travelling in a straight line.

How to activate the Diff-lock

1. For Foot-Pedal Control

- a) Return the forward/reverse pedal to neutral position to stop the machine.
- b) Check to see that the rear wheel is in the straight-ahead position.
- c) Press and hold in the diff-lock button.
- d) Increase the engine revs to full RPM.
- e) Depress the forward/reverse pedal lightly in the required direction.
- f) Do not overload the engine.
- g) The diff-lock may be released while the machine is in motion.

2. For Automotive Type Control

- a) Release the accelerator pedal to stop the machine.
- b) Check to see that the rear wheel is in the straight-ahead position.
- c) Press and hold in the diff-lock button.
- d) Select forward or reverse.
- e) Increase the engine RPM to move the machine.
- f) Drive the machine slowly while the diff-lock is engaged.
- g) The diff-lock may be released while the machine is in motion.

4. OPERATING PROCEDURES

Stopping Procedure

When stopping the machine follow the sequence below:

- Neutralise all hand control levers, the accelerator and the forward/reverse pedal.
- Lower the forks to the ground.
- Engage the park brake.
- Switch off the ignition and remove the key.
- Release the seatbelt.
- Dismount using the 3-point contact method.



WARNING:

If the Forward/Reverse pedal does not return to the neutral position, do NOT use the machine and contact your supervisor.



WARNING:

Never leave the operators seat with out first

- Facing the machine uphill and turning the rear wheel sideways if stopped on an incline.
- Lowering the forks to the ground.
- Placing all controls in the neutral position.
- Engage the park brake.
- Turn of the engine.

Loose Articles

Remove or secure all loose articles in the operators compartment - such as lunch boxes, tools etc.



WARNING:

Loose articles can fall and strike you, or roll on the floor. You could be knocked unconscious, or the controls could get jammed. If that happens you could lose control of the machine.



CAUTION:

If something comes loose, breaks or fails to operate:

- Stop.
- Shut down the engine.
- Get it repaired.

4. OPERATING PROCEDURES

Basic Load Techniques


Travelling without a load:

- Always extend the mast fully forward.
- Keep the forks as low as possible.
- Never travel with mast back and no load.



WARNING:

No Load. When travelling without a load the mast **MUST** always be fully extended



Travelling with a load:

- Keep the mast fully retracted when travelling.
- Lower the stabilisers fully before extending the mast to place a load.
- When lifting a load keep the stabilisers fully lowered until the mast is fully retracted.
- Keep the load as low as possible.



WARNING:

Stabilisers. When placing a load, always place the load on firm and level surface. The stabilisers must always be fully lowered before attempting to extend the mast. When lifting a load, the stabilisers must be fully lowered and raised only when the mast is fully retracted.



DANGER:

Stabilisers. Never raise the stabilisers when the mast carriage is extended with a load on.

Note: When the ground is not firm enough to support the stabilisers extra support plates must be used of sufficient size and strength to ensure they do not sink, bend or buckle during operation. A second person may be required to check the support plates.



If at any time the stabilisers or pads show sign of sinking the procedure must be stopped immediately, the mast carriage fully retracted and an alternative location found. If in doubt prior to or during an operation on loose, uneven or soft surfaces, stop. Always consider safety first.

4. OPERATING PROCEDURES


Lifting And Placing Loads

A. CUBED LOADS


A cubed load is one that fits between the front wheels and the frame of the machine. To achieve maximum machine and load stability, the load should be carried with the mast fully back and as low as possible between the frame of the machine at all times. A common type of cubed load would be bricks, blocks, bagged goods or turf grass.



Brick / Stone




Turf Grass




Bagged Goods

Lifting a cubed load from ground level


Note: Make sure the load to be lifted is stable and secure. Check the weight and load centre of the load to be lifted. If the weight is not marked or shown on the load, check the weight of the load with your supervisor or have it weighed. If it is too heavy, split the load and restack it.



1. Align the forks to suit the load.
2. Approach the load squarely and drive slowly forward until the forks are fully engaged.
3. Check that the surface is strong enough to support the stabilisers. If not, place a metal or wooden support underneath which is strong enough to support the stabilisers.




4. Lower the stabilisers fully.
5. Tilt the mast rearwards slightly to secure the load.
6. Raise the forks to lift the load.



7. Side-shift the mast to the centre position.
8. Retract the mast fully.
9. Raise the stabilisers fully.
10. Slowly drive away looking in the direction of travel.


4. OPERATING PROCEDURES

Travelling with a cubed load




1. Carry the load as low as possible between the frame of the machine.
2. Keep the mast retracted fully.
3. Tilt the mast back.
4. Do not side-shift the load while travelling or turning.
5. Use caution when starting or stopping. Drive slowly and avoid sudden movements.
6. Always look in the direction of travel.

Placing a cubed load at ground level



1. Check the area and be certain that the load can be safely placed.
2. Approach the placement area squarely.
3. Check that the surface is strong enough to support the stabilisers. If not, place a metal or wooden support underneath which is strong enough to support the stabilisers.
4. Lower the stabilisers fully.
5. Extend the mast fully.
6. Lower the forks to the ground.




7. Tilt the mast forward slightly to deposit the load.
8. Raise the stabilisers fully.
9. Back up carefully.
10. Drive away slowly looking in the direction of travel, keeping the mast extended fully.


4. OPERATING PROCEDURES

B. WIDE LOADS


A wide load is a load that will not fit between front wheels and frame of the forklift. A common type of wide load is piping or timber products.



Pipe






Timber



Plaster Board

Lifting a wide load


Note: Make sure the load to be lifted is stable and secure. Check the weight and load centre of the load to be lifted. If the weight is not marked or shown on the load, check the weight of the load with your supervisor or have it weighed. If it is too heavy, split the load and restack it.



1. Keep the mast extended fully.
2. Space the forks to suit the load.
3. Align the forks to suit the load, approach it squarely until the forks are fully engaged.
4. Check that the surface is strong enough to support the stabilisers. If not, place a metal or wooden support underneath which is strong enough to support the stabilisers.
5. Lower the stabilisers fully.
6. Raise the load to clear the ground.
7. Tilt the mast rearwards to secure the load.
8. Raise the load to clear the frame and wheels of the forklift.
9. Side-shift the mast to the centre position.
10. Retract the mast fully to bring the load above the front wheels.
11. Raise the stabilisers fully.


4. OPERATING PROCEDURES

Travelling with a wide load




1. Carry the load as low as possible above the frame of the machine.
2. Keep the mast retracted fully.
3. Tilt the mast back.
4. Do not side-shift the load while travelling or turning.
5. Drive slowly and avoid sudden movements.
6. Always look in the direction of travel.


Placing a wide load



1. Check that the area is clear of debris.
2. Approach the final position squarely.
3. Stop and side-shift the load if necessary to align it with the final resting position.
4. Check that the surface is strong enough to support the stabilisers. If not, place a metal or wooden support underneath, strong enough to support them.



5. Lower the stabilisers fully.
6. Extend the mast fully to clear the frame and wheels of the machine.
7. Lower the forks to the ground.



8. Tilt the mast forward slightly to deposit the load.
9. Raise the stabilisers fully.
10. Back up carefully.
11. Drive slowly facing the direction of travel, keeping the mast extended fully.




CAUTION:

When carrying wide loads your visibility may be blocked by the load. It may be safer to travel in reverse when moving with such loads. You may require a signal person or "spotter" to guide you. Do not drive uphill in reverse. If the street lights are blocked by the load the work lights must be used to improve visibility and ensure you are seen by other road users.

4. OPERATING PROCEDURES

C. NON PALLETIZED OR LOOSE LOADS

- Use skids when necessary to allow insertion of the forks beneath the load.
- Do not allow the skids to interfere with the fork placement.
- Secure loose loads to prevent them from falling or shifting
- Consult your supervisor before attempting to secure a loose load.
- Never attempt to handle a load which has been poorly wrapped or banded as it could injure you or others working around you.
- Follow the same procedure for handling cubed or wide loads when lifting or placing non-palletized or loose loads.



4. OPERATING PROCEDURES

Loads Above Ground Level

These techniques apply to:

- Stacking one load on top of another.
- Loading a truck or trailer.
- Unloading a truck or trailer.
- **Picking up a load above ground level (E.g. unloading a trailer)**
- Check the weight and load centre of the load to be lifted. If the weight is not marked or shown on the load, check the weight of the load with your supervisor or have it weighed. If it is too heavy, split the load and restack it.
- Adjust the fork height to suit the load.
- Centre the forks and approach the load squarely with the mast fully extended until the forks are fully engaged.
- Do not touch the pick-up area with the mast.
- Side-shift the mast to centre the load on the forks.

- Check that the surface is strong enough to support the stabilisers. If not, place a metal or wooden support underneath, strong enough to support them.
- **Lower the stabilisers fully.**
- If it is not possible to engage the forks fully, follow the procedure outlined in the section titled "Double Forking" until the forks are fully engaged. Raise the forks to lift the load clear of the pick-up area.
- Tilt the mast rearwards to make the load more stable.
- If necessary, raise the load to clear the frame of the machine.
- Retract the mast fully.
- **Raise the stabilisers fully.**
- Check behind and back up slightly to clear the pick-up area or vehicle body.
- Never manoeuvre or turn with a raised load.

- Lower the load as close to the ground as possible.
- Back out and drive away slowly, looking in the direction of travel.

Double Forking

If it is not possible to engage the forks fully when lifting the load from a truck or trailer, it will be necessary to move the load to the edge of the body of the vehicle before picking it up. This is known as "Double Forking". Remember that the lift capacity of the machine is reduced if the forks are not fully engaged.

To "Double Fork" the load

Raise the load slightly and retract the mast sufficiently to bring the load out to the edge of the vehicle body. Lower the load back on to the vehicle body and fully engage the forks by moving the mast forward again. The load is now ready to be lifted.

4. OPERATING PROCEDURES



WARNING:

Before attempting to load a truck or trailer, chock the wheels of the truck/trailer to prevent it moving. Always lower the stabilisers fully before attempting to pick-up from a truck or trailer.

Placing or stacking a load above ground level

- Approach the landing area squarely and with care.
- Side-shift the load if necessary.
- Raise the load above the level of the landing area or trailer.
- Drive forward carefully and make certain that the front of the machine does not hit the landing area or trailer.
- Check that the surface is strong enough to support the stabilisers.

Lower the stabilisers fully.

- Extend the mast fully until the load is directly above the landing area or trailer.
- Lower the load carefully.
- Tilt the mast forward to position the load and place it on the resting area.
- Raise the stabilisers slowly.
- Back up cautiously to clear the load and landing area.
- Lower the forks as low as possible to the ground.
- Back up slowly, looking in the direction of travel.



WARNING:

When lowering the stabilisers, make certain the ground is sufficiently firm to support the stabilisers. On loose or uneven soil, it may be necessary to place a flat wooden or metal support beneath the stabilisers.

Additional precautions when placing a load above ground level:

- Where visibility is restricted, use a signal person.
- Make certain that the landing area is of sufficient strength to carry the load.
- Also, check that the landing area is level and clear of debris.
- Never side-shift with a raised load. The stability of the Moffett truck-mounted forklift will be compromised and the machine may tip over.
- Always move controls in a smooth, steady manner. Do not force a hydraulic cylinder to the end of its stroke as the resulting "jolt" could spill the load.
- **Under no circumstances should a load be placed on or lifted from a scaffold platform.**

5. MOUNTING PROCEDURES

Introduction

The Moffett Truck-Mounted Forklift is designed to be transported on the rear of a truck or trailer.



WARNING:

A Moffett approved mounting kit must be fitted to your vehicle for transporting the Truck Mounted Forklift. Contact your truck mounted forklift distributor for further details of approved mounting kits


During transport the front wheels of the Moffett Truck-Mounted Forklift rest on the "wheel rests" of the mounting kit. The actual weight of the machine is supported by the wheel rests and steel transport chains. The stop lights and directional signal lights of the truck or trailer are connected to the Moffett Truck-Mounted Forklift by means of an electrical cable (wiring pigtail).



WARNING:

Do not attempt to transport the Moffett Truck-Mounted Forklift unless you have read this section of the manual very carefully!


Note: When the Moffett is not on the kit the rear bumper **MUST** be folded out and pinned at all times, ensuring lights are visible at all times.




5. MOUNTING PROCEDURES

Mounting Procedure


- On trailers, the folding rear bumper should be folded in and pinned on both sides.
- Approach the rear of the truck or trailer slowly and squarely. Extend the mast fully and centre the sideshift.
- Adjust the forks equally on the fork carriage to align them with the fork guides and ensure they are positively locked in place on the forkrail.




- Raise the forks to align them for entry between the fork guides.



- Drive slowly forward until the forks are fully engaged between the front and rear fork supports in the mounting kit.




- Tilt the mast fully rearward to raise the rear wheel.




- Lower the forks using the lift lever until the bottom of the front wheel of the forklift is slightly higher than the wheel rests of the mounting kit.
- Retract the mast fully to move the forklift forward "into" the mounting kit until the front wheels contact the wheel stops.

5. MOUNTING PROCEDURES



- Turn the steering wheel to ensure that the rear wheel is pointing straight ahead.
- Turn the engine off.
- Dismount using the three point contact method.
- Attach both transport chains securely to the rear of the truck or trailer and put the lock pins in place.



- Push and hold in the “ **Lower & Go**” button.

Note: if the machine is fitted with “**Groundstart**” press the bottom of the rocker switch to lower the machine.

- Observe that the forklift settles on the mounting kit.
- Connect the suzie cable and check that all lights are functioning properly.



CAUTION:

It is important to ensure the pigtail (suzie socket) connector is fitted correctly and that the lights on the rear of the Moffett Truck Mounted Forklift are functioning properly.

Note: Always ensure the park brake is off when mounting or dismounting the machine. Always wear your seatbelt, failure to do so will cause the park brake to automatically engage and make mounting difficult.



CAUTION:

It is important to release the hydraulic pressure as stated so that the weight of the Moffett Truck-Mounted Forklift is carried by the mounting kit and transport chains and NOT by the mast. Otherwise damage will result from the forklift’s weight resting on the mast.



CAUTION:

The rear bumper must be folded back out to full length and the locking pin and lynch pin fitted when the forklift is not being transported or removed for the purposes of loading or unloading.

Note: Always remember:

- To lower the forklift you must raise the mast.
- To raise the forklift you must lower the mast.
- To tilt the forklift up you must tilt the mast back.
- To tilt the forklift down you must tilt the mast forward.

5. MOUNTING PROCEDURES

Dismount Procedure


- Disconnect the electrical cable and store in a safe place.

Note: At this point there are 2 options available, depending on the specification of your machine.


OPTION A;

For machines **not equipped** with "Groundstart".

- Climb aboard using the three point contact method.
- Close the side guard fully.
- Fasten your seatbelt.
- Start the forklift.



- Raise the forklift off the wheel rests by lowering the forks until the wheels slightly clear the wheel rests.
- Tilt the mast fully rearward. The weight of the forklift is now on the forks.



- Turn off the engine.
- Unfasten seatbelt and open side guard fully.
- Dismount using the three point contact method.
- Close the side guard fully.


OPTION B;

For machines **equipped** with "Groundstart".

- The red isolator button must be pressed in fully at the same time as the top of the switch to activate the lift function. Observe that the forklift raises on the mounting kit and the chains become slack.

Note: Procedure is now the same for Options A & B


- Remove both slackened transport chains from the rear of the truck or trailer and place them in the hooks provided.



- Replace the pins and locks in the chain brackets.


5. MOUNTING PROCEDURES

- Open side guard fully and climb aboard the forklift using the 3-point contact method.
- Close the side guard fully.
- Fasten the seatbelt.
- Start the engine.
- Extend the mast slowly forward to move the forklift backward out of the mounting kit.



- Raise the forks to lower the forklift to the ground.
- Tilt the mast forward until the wheel touches the ground.

- Raise the mast slightly to pressurize the mast lift cylinder and to clear the fork brace. (This may take several seconds.)



- Ensure the rear wheel is pointing straight ahead.
- Back up slowly until the forks are fully clear of the front and rear guides.
- Lower the forks as low as possible, keep the mast extended fully and drive off, looking in the direction of travel.
- On trailers, the folding rear bumper should be extended and pinned on both sides.

- Before load handling it may be necessary to adjust the forks to suit the load or pallet.

Note: Always ensure that all Local and National laws are obeyed at all times. Make sure all operating and directional signal lights are functioning and visible. The rear bumper must be locked at full length when the forklift is not being transported.

Note: Always ensure the park brake is off when mounting or dismounting the machine. Always wear your seatbelt, failure to do so will cause the park brake to automatically engage.

5. MOUNTING PROCEDURES

Rules For Safe Transportation

If the forklift is to be driven on public roads, be certain that all laws and regulations are obeyed. Make sure all operating and directional signal lights are functioning and visible.

When travelling on public roads or streets, obey all local traffic movement regulations.

Approach intersections with caution, observe speed and traffic control signs. Do not speed. Avoid panic stops and sharp turns. When transporting the forklift on a truck or trailer know the overall height to avoid coming in contact with overhead obstructions such as bridges, power lines etc.



DANGER:

Do not attempt to transport the Moffett Truck-Mounted Forklift on a truck or trailer that is not equipped with a mounting kit designed and installed to Moffett Truck-Mounted Forklift specifications.

When carrying a Moffett Truck-Mounted Forklift, make certain that your vehicle complies with the relevant national and local laws and regulations regarding maximum vehicle weight, axle loading, overall vehicle length and overhang.

Note: Before mounting your machine on a truck or trailer ensure all relevant calculations have been carried out by an approved Moffett Truck-Mounted Forklift Distributor.

Ensure an approved Moffett mounting kit is fitted to the truck or trailer and that it is suitable to mount the particular Moffett Truck-Mounted Forklift.

All Moffett mounting kits must only be fitted by approved personnel.

6. MAINTENANCE

General

In order to carry out a service/inspection of your Moffett truck-mounted forklift it is important that the vehicle is first thoroughly cleaned, while doing so, please note the following points.

- Ensure that engine is shut down prior to washing
- Do not wash directly onto the roller bearings (mast rollers and side-shift rollers).
- Do not wash directly onto the mast chains, the mast chains must be cleaned using a kerosene-based cleaning agent and a brush. It is very important to remove all traces of the cleaning agent using an airline to blow dry the chains.
- Lubricate chains immediately after cleaning
- Take care when washing close to electrical connections.

Note: In some cases your Moffett Truck-Mounted Forklift may not have enough running hours required for carrying out a routine service as indicated in the intervals above, (i.e. the Moffett Truck-Mounted Forklift may only have 70 running hours or 90 days in a 12 month period).
Moffett Engineering Ltd. recommends in these cases that the Moffett Truck-Mounted Forklift is inspected/visited at least quarterly in each year. The type of service carried out depends on the environment that the machine is working in. It is very important to note that even though the Moffett Truck-Mounted Forklift may not be operated regularly it is carried on the rear of a truck/trailer and is subject to the harsh environment of driving on roads/motorways, i.e. road salt, rain snow etc. If you require any additional service information and/or clarification of the above please contact your nearest Moffett truck-mounted forklift Service Partner/Dealer or Moffett Engineering Ltd. directly.

When using compressed air ensure that relevant PPE(Personal Protection Equipment)/Safety equipment is used at all times. Adhere to all Company/Manufacturer safety information and guidelines.

6. MAINTENANCE

Introduction

In order to attain full benefit and service from your Moffett Truck-Mounted Forklift, it is important that the following service information/service guidelines are fully adhered to at all times. Moffett Engineering Ltd. recommends servicing take place at the following intervals:

1. Service at 50hrs or 60 days.
2. Next Service at 200 hours or 240 days and every subsequent 200 hour or 240 day intervals (200hrs, 400hrs, 600hrs, 800hrs / 240days, 480days, 720days etc.).
3. Additional items required at 1000 hrs or 1200 days (Refer to table 2 for information, items marked with an *).

Table 1 (see page 66) shows all the items/operations that require attention/inspection at each service. Each operation has a code indicating the type of action required. Table 1 shows the codes and there relevant terminology.

Note: As well as these service items it is recommended that you carry out a through daily maintenance as outlined from page 68



CAUTION:

The following outlines the recommended preventative maintenance schedule at 50, 200 and 1000 hour or 60, 240 and 1200 day intervals.

Always adhere to the recommended operating and maintenance procedures.

Only trained, authorized and experienced personel should be allowed to operate the Moffett Truck-Mounted Forklift. Service personel should read and study this manual, the service manual, the preventative maintenance and parts manual in order to gain a thorough understanding of the unit prior to making any repairs. Exercise all necessary safety precautions when preforming maintenance covered in the preventative maintenance manual. Ensure that the engine is switched off, the battery is disconnected and the engine and exhaust are cool.

6. MAINTENANCE

Maintenance Specifications Chart	
Code	Operation
CH	Change
CK	Check
G	Grease
CL	Clean
D	Drain
A	Adjust

Table 1

SERVICE DETAILS			
Operation	First Service at 50 Hrs or 60 days	Next Service at 200 Hrs or 240 days and every additional 200 Hrs or 240 days	* Additional Items required at 1000 Hrs or 1200 days
Change engine oil & oil filter element	CH	CH	
Change engine air filter element	CK	CH	
Change inline & main fuel element	CH	CH	
Change hydraulic return filter element			CH
Change hydraulic intank filter elements			CH
Change hydraulic oil			CH
Check/replenish coolant	CK	CK	
Check all bolts/nuts/fittings for tightness	CK/A	CK/A	
Check fan belt tension	CK/A	CK/A	
Carry out full electrical operational checks	CK	CK	
Carry out full hydraulic operational checks	CK	CK	
Adjust and lubricate lift chains	CK/A	CK/A	

6. MAINTENANCE

Operation	First Service at 50 Hrs or 60 days	Next Service at 200 Hrs or 240 days and every additional 200 Hrs or 240 days	* Additional Items required at 1000 Hrs or 1200 days
Grease all moving parts manually at specific grease points	G	G	
Check all wheel nuts for tightness (see Wheel Nut Specification Chart)	CK/A	CK/A	
Check all mast/carriage bearings for operation/wear	CK/A	CK/A	
Check rear arm bearings/bushings for operation/wear	CK/A	CK/A	
Check condition of tyres/rims	CK	CK	
Check for play in mast sections/carriage section	CK	CK	
Check mast lift chains for wear/missing parts/elongation	CK/CH	CK/CH	
Check/inspect condition of forks	CK	CK	
Check/inspect condition of seat/seat belt/overhead guard	CK	CK	
Check/inspect machine for all safety/functional decals	CK	CK	
Check oil cooler operation (if fitted)	CK	CK	
Test drive machine with/without weight	CK	CK	
Check transport lights on Moffett truck-mounted forklift with parent Truck/Trailer	CK	CK	
Inspect stabilizing chains for wear/missing/broken parts	CK	CK	
Check engine idling speed	CK/A	CK/A	
Check/adjust valve clearance on engine			CK/A
Remove radiator and clean all dust etc from between fins			CK/CL

6. MAINTENANCE

Daily Maintenance

Before you begin your work-day, take time to check your machine and make certain that all its systems are in good operational condition.

- Check for broken, missing or damaged parts.
- Check the forks, mast and lift chains.
- Check all hydraulic hoses and connections.
- Check the wheels for any damage or for missing or loose wheel nuts.
- Check the tyres for cuts, bulges, tread depth and proper inflation pressure.
- Check the engine oil level. Add oil if required (see section Service Specification, Engine Oil).
- If any parts are not ok contact your supervisor.
If operating in a dusty or sandy environment; Clean engine air filter element and replace if necessary.

- Clean all dust etc. from between radiator fins. Remove filter mesh from radiator and/or oil cooler where fitted and clean thoroughly. Where necessary, remove radiator for proper cleaning.
- Lift the engine cover and check the engine coolant level on the expansion bottle. Fill to the proper level if necessary. The proper coolant level is just below the radiator cap. Do not remove the radiator cap when the engine is hot. Escaping steam could cause severe burning (see section Service Specifications, Engine Coolant).
- Check the fuel level and top up if necessary.
- Check hydraulic oil level sight glass. Oil level must be between the red line (minimum) and the black line (maximum) when the mast is fully retracted and all hydraulic cylinders are in the

closed position. Top up if necessary (see section Service Specification, Hydraulic Fluid).



CAUTION:

Always turn off the engine and allow it to cool before checking:

- Engine coolant level
- Engine oil level
- Hydraulic oil level



CAUTION:

The hydraulic tank is pressurised and hydraulic oil may be hot. To avoid injury when removing the cap, stop the engine and remove the cap very slowly to avoid spillage.

6. MAINTENANCE

Interlocking seatbelt

Inspect the seat belt regularly to check for damage and to make sure it functions properly mechanically and electrically.



WARNING

- Failure to properly inspect & maintain the seat belt can cause serious injury or loss of life in an accident.
- When being driven if the Moffett Truck-Mounted Forklift is involved in an accident the whole seatbelt assembly must be replaced. This is to ensure that if any unseen damage has occurred it is replaced.
- If the seatbelt is worn or damaged it must be replaced.

- The seatbelt must be inspected in detail at least once a year and more often if exposed to harsh conditions.
- If replacement of any part of the seatbelt is required then the entire assembly must be replaced (Retractor and Buckle) with Moffett Engineering Ltd. recommended items from a service provider.

Inspection

The following guidelines detail how to inspect the Seat Belt fitted to a Moffett Truck-Mounted Forklift:

1. Webbing - To check the webbing pull the seatbelt completely out of the retractor and inspect the full length for deterioration. The Seatbelt must be replaced if it has any signs of nicks, cuts or holes, is frayed or fluffed at the edges, shows excessive fading due to UV

exposure, if the webbing is packed with dirt or if the stitching is frayed, insecure, incomplete or repaired.

2. Buckle Operation - Check buckle for damage and check the latch for correct operation. Also determine if latch plate is excessively worn, deformed or buckle is damaged or casing is broken. Check security and operation by connecting the buckle and tongue, then try to pull apart; while pulling, press button to ensure correct release. Make sure the button does not stick after release.

3. Retractor - Fully extend the webbing to determine if the retractor spools in and out correctly. All webbing must retract back fully into the retractor. When the webbing is quickly pulled from the retractor the belt should lock automatically.

6. MAINTENANCE

4. Connection to Forklift - The seatbelt anchorage points should be checked to ensure all bolts are tight. Check the mounting plates are OK and in the case of the flexible cable type seat belt ensure that the cable is not broken or frayed.

5. Electrical Connection

The seat belt is fitted with an electrical connection and wired to the machine, check that the wire is not cut, pinched or damaged in any way and ensure when seatbelt is disconnected that the machine will not drive.

If the inspection finds any damage, wear, or malfunction of the seatbelt, the complete unit must be replaced with OEM recommended equipment. The seatbelt fitted has been designed and tested specifically for the Moffett Truck-Mounted Forklift. Care must be taken when replacing parts to ensure that they are fitted correctly to

maintain the integrity and function of the Seat Belt system.

Note: The seatbelt must only be cleaned with warm soapy water; do not use chemical cleaners, bleach or dyes. Contamination with fuel, grease or acid will damage the seatbelt. Do not make any modifications or additions to the seatbelt.

6. MAINTENANCE

DAILY PRE-SHIFT INSPECTION CHECKLIST

Visual Checks

The Moffett Truck Mounted Forklift must be parked on a firm level surface in a SAFE ZONE with the keys removed and the park brake engaged. Starting at the operator station, walk around the forklift and complete the following visual checks.

If defects are identified during the pre-shift visual inspection, notify your supervisor immediately.

- 1 **Decals** - no missing, damaged, or faded decals on the forklift.
- 2 **Seat** - must not be loose; vinyl should not be torn.
- 3 **Seat Belt** - The seat belt should extend smoothly and retract fully. The seat belt must not be frayed or worn. The mechanical latch must be fully functional.
- 4 **Side Guard/Latch/Hinges** - should not have any cracks or bends; must open and close smoothly; must positively latch when closed; **should not be removed.**
- 5 **Overhead Guard** - must not be bent, cracked or modified by drilling or welding.
- 6 **Operator Manual/Manual Box** - *Moffett Operator Manual* must be in the manual box at all times.
- 7 **Hydraulic Level Oil Sight Gauge** - check the hydraulic fluid level with all cylinders in the CLOSED position; top off ONLY with the specified hydraulic fluid; if discoloured, inspect oil system.
- 8 **Fuel Level** - top off if necessary; do not overfill tank; ensure that seal on the inside of fuel cap is not damaged.
- 9 **Valve Levers** - should be clean and clear of debris.
- 10 **Left Carriage Cylinder** - Check for leaks at the fitting and glands (where the cylinder rod extends and retracts). Check for scratches and nicks on the cylinder rod. Check the mounts for cracks on either end of the cylinder. Check for missing or loose bolts on the cylinder retaining pins at either end of the cylinder.
- 11 **Left Tilt Cylinder** See #8 Left carriage cylinder.

6. MAINTENANCE

Visual Checks (continued)

- 12 **Left Front Tyre and Wheel** - Look for debris, mud, or binding behind and around the wheel. There should be no missing or loose wheel nuts. There should be no chunks, cuts, or excessive wear on tyre. Check for proper inflation, REPLACE if the body ply cords are visible, or show any signs of cuts, bulges, or other signs of damage, or has a loss of traction (regardless of tyre tread height). Look for bent or corroded rims.
- 13 **Left Load Support (M5 4-way)** –should fold up and down smoothly. It should latch/lock positively when folded up.
- 14 **Sideshift Cylinder**– See #10 Left carriage cylinder.
- 15 **Left Sideshift Pin** - Check for missing or loose bolts on either end.
- 16 **Left Stabiliser** - Check for damage and ensure the wear pads are intact and adjust with shims if necessary.
- 17 **Left Fork** - lock pins should be functional and making positive engagement in fork board; check the top and bottom carriage mountings for cracks and wear; check the fork for bends, cracks, and wear horizontally (along the blade), vertically (along the shank), and at the heel; ensure that both forks are in the same level plane.
- 18 **Mast** - Check that mast is not bent or has any debris; check the bolts on the base of the mast cylinder for tightness.
- 19 **Mast Chains** - All 4 mast chains should be lubricated; there should be no seized links or rotated connecting pins over the entire length of all 4 chains, they should all be adjusted correctly with no slack in chains.
- 20 **Load Backrest** (*if fitted*) -The load backrest should not be bent or loose.
- 21 **Mast Lift Cylinder and Mounts** – See #10 Left carriage cylinder.
- 22 **Hydraulic Hoses and Connections** - Observe any leaks or loose fittings. Look for oil spots on the ground where the forklift has been parked and on the frame of the forklift for the source of a leak.
- 23 **Right Fork** –See #17 Left fork.
- 24 **Right Sideshift Pin** – See #15 Left sideshift pin.
- 25 **Right Stabiliser** – See #16 Left stabiliser pin.

6. MAINTENANCE

Visual Checks (continued)

- 26 **Right Load Support (M5 4-way)** – See #13 Left load support.
- 27 **Right Front Tyre and Wheel** – See #12 Left front tyre and wheel.
- 28 **Right Tilt Cylinder** – See #10 Left carriage cylinder.
- 29 **Right Carriage Cylinder** – See #10 Left carriage cylinder.
- 30 **Top Hood** – no broken latches or hinges.
- 31 **Air Filter Indicator** – Push the spring-loaded button (if fitted) – replace if it does not return.
- 32 **Engine Oil** – mark should be between the minimum and maximum; top off if below minimum.
- 33 **Coolant** – check Min / Max level on the overflow bottle which is connected to the radiator: **Do not attempt to remove the radiator cap if the engine is hot.**
- 34 **Rear Steering Cylinder** – See #10 left carriage cylinder.
- 35 **Rear Tyre and Wheel** – See #12 Left front tyre and wheel.
- 36 **Rear Door** – no broken latches or hinges; air filter rain cap should be in place.

NOTE: IF DEFECTS ARE IDENTIFIED DURING THE PRE-SHIFT VISUAL INSPECTION, NOTIFY YOUR SUPERVISOR IMMEDIATELY.

6. MAINTENANCE

Operational Checks

Operational inspections are done by starting the engine, operating all controls, and test driving. Never start a forklift to perform the operational inspections if the visual inspection indicates immediate safety hazards. Constantly monitor the gauges, listening for unusual noises, loose parts, fluid leaks, and unusual conditions. If a problem is suspected, take the forklift out of service and have it inspected and repaired.

- 1 **Noises/Emissions** – no unusual noises and observe engine emissions.
- 2 **Gauges and Indicators** – engine oil light and the battery light should illuminate when the ignition turned on and then go out when the engine is started; preheat indicator (if equipped) should illuminate when preheating and go out after the engine is started; temperature gauge should rise to the safe operating temperature range when operating.
- 3 **Hour Meter** – should “count” as the forklift is operated.
- 4 **Pedals** – depress the accelerator pedal slowly and return to neutral; engine should run smoothly and accelerate/decelerate to idle; drive the forklift forward and backward at low RPM (depressing the forward/reverse pedal fully in each direction) - forklift should respond accordingly; releasing the forward/reverse pedal should stop the Moffett Truck Mounted Forklift.
- 5 **Seat Belt** - The internal electrical isolator switch must be functioning i.e. when the seatbelt is disconnected the drive pedal isolated machine will not drive.
- 6 **Valve Levers** - cycle all controls fully; there should be no free play in the valve levers; look for jerking movement and listen for unusual noises; all levers should return to the centre position (neutral) when released.
 - **Stabilisers** – both stabilisers lower and raise fully.
 - **Carriage** – mast carriage should move forward and backward fully and smoothly without lateral movement.
 - **Mast** – the mast should raise and lower fully and smoothly.
 - **Tilt** – there should be no binding or jerking when tilting the mast fully forward and rearward.
 - **Sideshift** – there should be no binding or jerking when the mast is sideshifted fully left and fully right.
- 7 **Park Brake (ON/OFF)** – the Moffett Truck Mounted Forklift should not move when the park brake is on.

6. MAINTENANCE

Operational Checks (continued)

- 8 **Steering Response** – the steering should be responsive; no excessive free play, jerking, binding, or unusual noises.
- 9 **Diff-Lock (FWD/REV)** – there will be a noticeable drag on the engine when diff-lock is engaged and attempt to drive forward and reverse.
- 10 **Engaging the Lateral 4-Way Mode (M5 4-Way)** – engage the lateral mode, travel to right and left, steering is precise and smooth.
- 11 **Disengaging the Lateral 4-Way Mode (M5 4-Way)** – engage the normal mode, front wheels should return to “straight ahead position”: travel backward and forward.
- 12 **Back-up Alarm** – must be operational; **the back-up alarm should NEVER be disconnected.**
- 13 **Horn** – should be operational; **do not operate forklift if horn does not work.**
- 14 **Work Lights** – all work lights should be operational.
- 15 **Street lights** – all street lights should be operational.
- 16 **Strobe (if fitted)** – should be operational when the ignition is switched to the ON position.

NOTE: IF DEFECTS ARE IDENTIFIED DURING THE PRE-SHIFT OPERATIONAL CHECK TAKE THE FORKLIFT OUT OF SERVICE NOTIFY YOUR SUPERVISOR AND HAVE IT INSPECTED AND REPAIRED.

6. MAINTENANCE

Transport Checks


Transport inspections are done by inspecting the mounting kit and then mounting the Moffett Truck Mounted Forklift onto a truck or trailer before making deliveries. Never attempt to mount the forklift to perform the transport inspections if the visual or operational inspections indicate immediate safety hazards. If a problem is suspected with the mounting kit or forklift, take the either the mounting kit or forklift out of service and have it inspected and repaired.

- 1 **Mounting Kit** – Check the mounting kit and chain hanger brackets for cracks and bends.
- 2 **Tie Downs** (*Dump Bed Mounting Kit only*) – The tie downs should be positively locked in place.
- 3 **Pins and Locks** – Ensure that the transport pins on either side are not worn and that both flip locks are working
- 4 **Transport Chains** – Check for damaged or dislodged pins on the end shackles at either end of both chains. The bolts and lock nuts that retain the transport chains on either side of the Moffett Truck Mounted Forklift should be in place. Mount the forklift on the rear of the truck or trailer. **If any unusual noises, jerking, or binding are noticed, immediately lower the forklift to the ground and have it inspected by a forklift technician**
- 5 **Angle of Forklift to Ground and Ground Clearance** (*when mounted*) – The rear wheel should be 75-100mm higher than the front wheels when mounted. The rear wheel should be pointed forward at all times.
- 6 **Rear Bumper Lights** (*when mounted*) – All rear bumper lights should be working:
 - side marker (left and right)-2
 - corner marker (left and right)-2
 - back-up x1 or x2
 - stop-2
 - tail -2
 - turn-2
- 7 **Conspicuity Tape** (*when mounted*) – The conspicuity tape should be clean and intact on the rear as well as the left and right side of the forklift.

NOTE: IF DEFECTS ARE IDENTIFIED DURING THE PRE-SHIFT TRANSPORT CHECK TAKE THE KIT OR FORKLIFT OUT OF SERVICE NOTIFY YOUR SUPERVISOR AND HAVE IT INSPECTED AND REPAIRED.

6. MAINTENANCE


Grease Point Chart



ITEM	DESCRIPTION	No. OF POINTS	PAGE NUMBER	ITEM	DESCRIPTION	No. OF POINTS	PAGE NUMBER
1	Steering Linkage	1	78	8	Mast Lower Section	2	81
2	Spindle Housing	3	78	9	Tilt Cylinder	4	82
3	Steering Cylinder	2	78	10	Side Shift Cylinder	2	83
4	Fork Carriage	4	79	11	Mast Carriage	4	84
5	Top Chain Rollers	2	80	12	Side Shift Bushing	2	85
6	Bottom Chain Rollers	2	80	13	Lift Cylinders	2	86
7	Mast Upper Section	2	81	14	Rotating Side Guard	1	87


6. MAINTENANCE

Steering Linkage, Spindle Housing And Steering Cylinder Grease Points




6. MAINTENANCE

Fork Carriage Grease Points




6. MAINTENANCE

Chain Rollers Grease Points




6. MAINTENANCE

Mast Section Grease Points




6. MAINTENANCE

Tilt Cylinder Grease Points




6. MAINTENANCE

Sideshift Cylinder Grease Points





6. MAINTENANCE

Mast Carriage Grease Points



6. MAINTENANCE



Sideshift Bushing Grease Points



6. MAINTENANCE


Lift Cylinder Grease Points

Location of lift
cylinder on machine



6. MAINTENANCE

Rotating Side Guard



Grease Points On Side Guard

Side Guard Hinge 1

6. MAINTENANCE

Engine Oil

Engine oil should be MIL-L2104C or have properties of API classification grades or higher. Change the type of engine oil according to the ambient temperature.

When using oil of different brands from the previous one, be sure to drain all the previous oil before adding the new engine oil.

AMBIENT TEMPERATURE	OIL SPECIFICATION		
Above 25°C (77°F)	SAE30	Or	SAE 10W-30 SAE 10W-40
0 to 25°C (32 to 77°F)	SAE20	Or	SAE 10W-30 SAE 10W-40
Below 0°C (32°F)	SAE10W	Or	SAE 10W-30 SAE 10W-40

Engine Coolant

A mix of 50% permanent type antifreeze and 50% distilled water should be used to fill the cooling system. The coolant mix inhibits corrosion and gives the system protection down to -37°C (-34°F). A good quality coolant with a specific gravity of 1.080 at 15.5°C (60°F) should be used. The antifreeze should comply with one of the following specifications:

SAE J1034
BS 6580: 1985
MIL - A - 11755D
MIL - A - 461 53/B

The concentration of the coolant may deteriorate over a period and therefore should be checked at least once a year or at each 200 hour's service whichever whichever occurs first.

6. MAINTENANCE

Engine Fuel Specification

Use No.2-D – a distillate fuel oil of lower volatility for engines in industrial and heavy mobile service. (SAE J313 Jun87) Grade of Diesel Fuel Oil (According to SATM D975). Be sure to use a strainer when filling the fuel tank, as dirt or sand in the fuel may cause trouble in the fuel injection pump. Always use diesel fuel. You are required not to use alternative fuel, because its quality is unknown or it may be inferior in quality. Kerosene, which is very low in cetane rating, adversely affects the engine. Diesel fuel differs in grades depending on the temperature. Refer to the following tables for specific minimum and maximum fuel properties.

Flash Point, °C (°F)	Water and Sediment Volume %	Carbon Residue on, 10% Residuum, 1%	Ash, weight %
Min	Max	Max	Max
52 (125)	0.05	0.35	0.01

Distillation Temperature °C (°F) 90% Point		Viscosity Kinematic cSt or mm 2/5 at 40°C		Viscosity Saybolt SUS At 100°F		Sulphur, Weight %	Copper Strip Corrosion	*Centane Number
Min	Max	Min	Max	Min	Max	Max	Max	Min
282 (540)	338 (640)	1.9	4.1	32.6	40.1	0.50	No.3	40

6. MAINTENANCE

Hydraulic Fluid

Oils conforming to the International Standard I.S.O. 6743-4HV VG grade oils with improved viscosity/temperature characteristics should be used. (Some countries may still use DIN 51524 PART 3). The hydraulic oil used in the Moffett truck-mounted forklift must have the correct temperature range for the ambient temperature in which the machine is being operated. If the operating temperature is outside the standard range, the standard oil should be replaced with the correct grade. Some examples of commercially available oils are listed below. Make sure the correct type is used in the relevant ambient environment.

Note:

1. The sequence in which the brand names are listed does not signify any grading as to their quality or preference.
2. M50, M4000 and M5000 are supplied with the standard-range hydraulic fluid.
3. P5000 is supplied with the high-range hydraulic fluid.

AMBIENT TEMPERATURE	Low Range -20°C to 25°C -4°F to 77°F	Standard Range -10°C to 35°C 14°F to 95°F	High Range 0°C to 45°C 32°F to 113°F
Castrol: Hysin	AWH 32	AWH 46	AWH 68
BP: Bartran	HV 32	HV 46	HV 68
Esso: Univis	N 32	N 46	N 68
Mobil:	13 M	15 M	16 M
Shell: Tellus Oil	T 32	T 46	T 68
Texaco:	HDZ 32	HDZ 46	HDZ 60

6. MAINTENANCE

Chain Lubricant Specification

The lubricant oil's viscosity should be chosen so that it will remain fluid at all occurring ambient temperatures. Under normal temperature conditions, lubricating oils with a viscosity from SAE 20 to SAE 40 (50 to 2000mm²/s at 40°C) are suitable. The following are examples of commercially available chain-lubricating products.

1. Rexnord High-Performance Chain Spray.
2. BP Energol Transmission Oil 80.
3. ESSO Transmission Oil ST80.
4. Shell Tonna Oil T200.

Grease Specification

The recommended grease for all moving parts is Lithium EP2 or equivalent specification. This is particularly important for all bearings and rollers.

Tyre Inflation

See chart for recommended tyre inflation pressures used by Moffett Truck-Mounted Forklift.

*It is recommended that tread depth should never fall below 20% of original tread depth.



WARNING:

Using compressed air can be dangerous. Obey all statutory notices and apply all relevant health and safety regulations.

Specification PSI(Bar)

26x12-12 (12ply) - 65(4.5)
27x10-12 (14 ply) - 102(7.0)
29x12.5-15 (8 ply) - 46.5(3.2)
280x60-15.5 (6 ply) - 51(3.5)

4-Way

27x10.5-15 (8 ply) - 60(4.1)

Wheel Nut Torque		
Model	Torque	Wheel Nut P/N
M5	200 Nm, 150lbf.ft	503.055.0345

6. MAINTENANCE

Noise Data

Noise (In accordance with EN12053)

- | | | |
|----|----------------------|-------------|
| 1. | Sound Power Level | 101 LWA dB |
| 2. | Sound Pressure Level | 84.7 LPA dB |

Vibration Data

Vibration (In accordance with EN13059)

- | | |
|---|------|
| Weighted rms Acceleration
Whole Body Vibration (m/s^2) | 1.35 |
| Weighted rms Acceleration
Hand-Arm Vibration (m/s^2) | 2.57 |

7. SPECIAL PROCEDURES

Jump Starting

Safety



WARNING

If you are unsure how to follow this procedure, we strongly recommend that you seek help of a competent mechanic.

Batteries contain sulfuric acid which is poisonous and corrosive. Wear protective safety glasses when jump starting, and avoid spilling acid on your skin, clothing or vehicle.

Do not try to charge a frozen battery. If you try to charge a frozen battery, or jump start and run the engine, the battery could explode.

Do not use the battery if the electrolyte is frozen. To prevent the battery electrolyte from freezing, keep the battery at full charge.

Do not smoke when checking the battery electrolyte levels. Batteries give off a flammable gas that can explode. When starting another machine, make sure the two machines do not touch as this could cause sparks. Sparks could ignite the battery gas. If this happens the battery could explode.

Even with the starter switch set to the off position some circuits will still be energized when the external power supply is connected. Ensure all machine switches are set to the off position before connecting the external power supply.

Only use jump start cables that are in good condition with securely attached connectors.

Connect both ends of one jump start cable before connecting the other cable.



CAUTION:

The booster supply should not be more than 12 volts. Using a higher voltage supply will damage your machines electrical system. Do not connect two batteries together to give 24 volts. This could burn out the induction manifold heater and damage the starter motor.



WARNING:

Keep all metal straps and fasteners from clothes or jewelry clear of the positive terminal (+) battery terminal. Such items can cause a short between the battery terminal and nearby metal framework. If this happens you could get burned.


7. SPECIAL PROCEDURES

Jump Starting (continued)

Procedure

Note: Your machine has a 12 volt starting system. The negative (-) is connected to the engine cylinder block.

- A) Make sure that the park brake is engaged and the forward / reverse pedal or lever is in neutral.
- B) Ensure all switches are set to the off position.
- C) Open the rear door.
- D) Connect the positive cable to the positive terminal jump start plug. Connect the other end of this cable to the positive (+) end from the booster supply.
- E) Connect the negative (-) cable to the ground point on the machine. The engine mount bolts are easily accessible as a ground point.
- F) Connect the other end of the negative (-) terminal from the booster supply.
- G) Start the engine. (Refer to Starting the Engine)
- H) Disconnect the negative (-) booster cable from the Moffett, then dis-connect it from the booster supply. Disconnect the positive (+) terminal from the jump start point on the Moffett then disconnect it from the booster supply.
- I) Close and lock the rear door.



8. ATTACHMENTS

Using other Attachments

The Moffett Truck Mounted Forklift is available with a range attachments fitted from the factory. The general rule is that any attachment used on this forklift must be intended for the function of lifting only. This forklift is not designed to PULL, TOW or DRAG other objects. DO NOT use attachments that perform these functions with this forklift.

All Moffett machines supplied with attachments have special capacity charts taking into account any additional attachment weight and lost load centre and how this affects the stability and capacity of the machine. Third party suppliers may not supply this information with their attachments and so only approved attachments must be fitted to the Moffett Truck Mounted Forklift.

Moffett makes no representations or warranties, express or implied, as to the design, manufacture or fitness for use with this forklift of any third party source attachments.

This forklift is not intended to be used and should not be used with any attachment that would alter the centre of gravity stability of this forklift. Moffett assumes no liability for any third party attachment that would alter the centre of gravity stability.

If in doubt contact your local Moffett dealer for advice.




Operator Manual

Moffett Truck Mounted Forklift With Lift Assist and Reach Device

Note:

This section of the manual describes additional operating instructions for the Moffett Truck-Mounted Forklift Lift Assist and Reach Device unit and should only be used as a supplement to the operator manual.



Delivering **Confidence**

B - LIFT ASSIST AND PANTOGRAPH

Overview

“Lift Assist”™ is an attachment which increases the capacity of the machine. When fitted in conjunction with a pantograph reach device allows the machine to lift increased capacity from extended load centres.

It is designed to be used over a truck / trailer bed and **MUST NOT** be used in any other circumstances.

Lift Assist reacts the extra load moment of the extended load centre into the side of the truck / trailer bed and enables an increased capacity to be lifted from extended load centres.

Lift Assist relies on good stabiliser friction to react the extra load moment into the side of the truck / trailer. To ensure this reaction takes place the stabilisers are fitted with friction pads and they **MUST NEVER** be raised while Lift


Assist is in use and the stabilisers **MUST ALWAYS** be placed on firm level ground.

If at any time during any lifting operation stabiliser friction is compromised then the load being lifted **MUST** be lowered and a smaller load lifted or alternative ground conditions with improved stabiliser friction must be found.

The “Lift Assist”™ system is fitted with a changeover valve which utilizes the stabiliser hydraulic feed to operate the Lift Assist arms as required. When the hydraulics are used to raise the arms of the Lift Assist the force they can generate is limited to ensure they do not exert any rearward force on the machine during deployment.

When the lift Assist arms are deployed they are prevented from being forced down by check valves in the system.

“Lift Assist”™ Attachment



Stabiliser Friction Pad

B1. SAFETY CHECKLIST – LIFT ASSIST AND PANTOGRAPH

Safety Checklist

Note: The additional Safety Checklist in this section is specific to Lift Assist and Pantograph or other reach device. This should be used in conjunction with the Safety Checklist for the standard machine as outlined at the start of this manual.



WARNING:

Procedure. The “Lift Assist” function must only be used as outlined in the operating procedures of this manual.



WARNING:

Capacity. Do not exceed the capacity shown on the Load Chart for “Lift Assist” in combination with Pantograph or other reach device.



WARNING:

Stabilisers. Make sure the stabilisers are on firm ground or pavement before using Lift Assist.



WARNING:

Stabilisers. Never raise stabilisers while Lift Assist arms are extended. Always retract Pantograph and retract Lift Assist Arms prior to raising stabilisers.



WARNING:

Stabilisers. Make sure the stabiliser friction pads are fitted and are in good condition.



CAUTION:


Truck Mounting. Never truck mount with the Pantograph or reach device extended. Always truck mount with the Pantograph retracted as outlined in the normal mounting procedure.

Note: If an operator attempts to truck mount the machine with the pantograph extended then the Pantograph system will lock. The operator **MUST** lower the machine and remove the pressure from the Rod side of the Lift Cylinder before the Pantograph Unlocks.

B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Major Compone


1. Pantograph Device
Telescopic forks.
2. Scissor Cylinder.
3. Pantograph Mast.
4. Lift Rams x2.
5. Hydraulic Controls
6. Nylon Wear Strip.
7. Lift Assist Arms.
8. Stabiliser Friction



Note: If the stabiliser friction pads become excessively worn, damaged or are missing, Do Not use the lift assist function as its performance will be reduced.

B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Safety Decals



Note: The additional Safety Decals listed in this section are specific to Lift Assist and Pantograph and should be used in conjunction with the Safety decals on the standard machine.

Part No. 517.065.0013

WARNING

LIMITATIONS OF LIFT ASSIST SYSTEM


THE LIFT ASSIST ARMS ON THIS MACHINE ENABLE THE MACHINE TO LIFT LOADS FROM EXTENDED LOAD CENTERS AS OUTLINED ON THE LOADCHART. ALWAYS REFER TO OPERATORS MANUAL FOR CORRECT OPERATION PROCEDURE BEFORE USING LIFT ASSIST.

THE LIFT ASSIST ARMS **MUST ONLY** BE USED TO LIFT LOADS WHEN:

- BOTH STABILIZERS ARE **FULLY** LOWERED ON A FIRM LEVEL SURFACE OF CONCRETE OR ASPHALT (SEE NOTE).
- BOTH LIFT ASSIST ARMS ARE **FULLY** UP AND ARE IN CONTACT WITH THE SIDE OF THE TRUCK OR TRAILER BED.
- THE LOAD TO BE LIFTED ALWAYS STAYS **OVER** THE TRUCK / TRAILER BED UNTIL THE REACH DEVICE IS **FULLY RETRACTED** AND THE LIFT HEIGHT DOES NOT EXCEED THE LIFT CAPACITY INDICATED ON THE LOAD CHART.


NOTE: IF DURING THE LIFTING OPERATION THE STABILIZERS START TO SLIP THE LOAD MUST BE LOWERED IMMEDIATELY AND A SMALLER LOAD - LOAD CENTER LIFTED OR IMPROVED GROUND CONDITIONS ARE FOUND.

517.065.0013



B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Safety Decals (continued)





B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Safety Decals (continued)

Note: The additional Safety Decals listed in this section are specific to Lift Assist and Pantograph and should be used in conjunction with the Safety decals on the standard machine.

Part No. 517.999.0113






Note: The valve bank and load chart decals in this section are only examples and may differ from those found on your machine.

B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Safety Decals (continued)

Note: The additional Safety Decals listed in this section are specific to Lift Assist and Pantograph and should be used in conjunction with the Safety decals on the standard machine.

Note: Additional Decal Eng011 also on RH side but not shown.



B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Instruments And Controls Hydraulic Levers

The Lift Assist and Pantograph machine is fitted with two (x2) dual function levers. The function of these levers is outlined below and on the Valve Bank Decal.

UNDERSTAND THE FUNCTION OF BOTH LEVERS FULLY BEFORE OPERATING THE MACHINE!

A. Forks – Raise and Lower:

This lever raises and lowers the forks. Forward movement of the lever will lower the forks (down). Backward movement of the lever will raise the forks (up).

B. Mast or Pantograph or Telescopic Forks:

This lever is fitted with a button which gives the lever two functions **B1** and **B2**.

B1. Mast – Extend and Retract

Without the red button pressed (**off**) this lever moves the mast forwards and backwards. Forward movement of the lever extends the mast forward, away from the operator (out). Backward movement of the lever retracts the mast backward towards the operator (in). When placing a load, the mast should be extended only when the stabilisers are fully lowered.

B2. Pantograph or Telescopic Forks – Extend and Retract

With the red button Pressed (**on**) pushing the lever forward will extend the pantograph or telescopic fork section (out). Pressing the button (**on**) and pulling the lever backwards will retract the pantograph or telescopic fork section (in).

C. Tilt Mast – Forward and Back:

This lever tilts the mast forwards and backwards. Forward movement of the lever tilts the mast forward (Forks Down). Backward movement of the lever tilts the mast rearward (Forks Up). Loads should normally be transported with the mast tilted back.

D. Side-Shift: This lever moves the mast to the right or left. Forward movement of the lever shifts the mast to the left. Backward movement of the lever shifts the mast to the right.

B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Hydraulic Levers (continued)

E. Stabilizers or Lift Assist:

This lever is fitted with a button which gives the lever two functions **E1** and **E2**.

E1. Stabilizers – Lower and Raise:

Without the red button pressed (off) this lever raises and lowers the stabilizing legs. When placing a load, the stabilizers must always be fully lowered before moving the mast forward. Moving the lever forward will lower the stabilizers (down). Moving the lever backwards raises the stabilisers (up). When lifting a load, never raise the stabilisers until the mast is fully retracted.

E2. Lift Assist – Raise and Lower

With the red button pressed (**on**) this lever raises and lowers the lift assist arms. Pressing the button (**on**) and moving the lever forward raises the lift assist arms (up). Pressing the button and moving the lever backwards lowers the lift assist arms (down).



Note: When the ground is not firm enough to support the stabilisers extra support plates must be used of sufficient size and strength to ensure they do not sink, bend or buckle during operation. A second person may be required to check the support plates. If at any time the stabilisers or pads show sign of sinking the procedure must be stopped immediately, the mast carriage fully retracted and an alternative location found. If in doubt prior to or during an operation on loose, uneven or soft surfaces, stop. Always consider safety first.

Note: If during the lifting operation the stabilisers start to slip the load must be lowered immediately and a smaller load – load centre lifted or improved ground conditions found.

B2. INTRODUCTION - LIFT ASSIST AND PANTOGRAPH

Hydraulic Levers (continued)

VALVEBANK DECAL - FUNCTIONS




B3. CENTRE OF GRAVITY - LIFT ASSIST AND PANTOGRAPH


Centre of Gravity – Load Moment

When “Lift Assist”™ is fitted in conjunction with a Pantograph or Reach device it adds to the machine’s restoring moment by reacting the extra overturn load moment created by the extended load centre into the side of the truck / trailer.

“Lift Assist”™ – Load Moment Force Diagram






The reaction into the side of the truck / trailer is counter reacted by the stabilisers (see below). To ensure this reaction takes place the stabilisers **MUST NEVER** be raised while Lift Assist is in use and stabilisers **MUST ALWAYS** be placed on firm level ground. If at any time during any lifting operation stabiliser friction is compromised then the load being lifted **MUST** be lowered and a smaller load lifted or alternative ground conditions with improved stabiliser friction must be found.



B4. OPERATING PROCEDURE - LIFT ASSIST AND PANTOGRAPH


Operating The Lift Assist And Pantograph

Note: These procedures are in addition to the operating procedures outlined for the standard machine in Section 4 of this manual.



1. Align the forklift and the forks with the centre of the load.
2. Approach at 90 degrees to the truck/trailer bed with the mast fully forward and the forks as low as possible.
3. Drive forward slowly until the front of the forks are approximately 150mm from the truck or trailer bed.
4. Tilt the mast forward to the vertical position and raise the forks to bed height.
5. Drive forward as far as possible without the mast making contact with the bed.
6. Do not contact the tires or any part of the truck or trailer with the stabilisers.
7. Extend the pantograph to fully to engage the pallet.
8. Ensure the surface is firm and level and then LOWER the stabilisers fully.
9. Never lower the stabilisers near the edge of a curb because they may slip off the edge or the edge may break away. Double fork the load if necessary.

B4. OPERATING PROCEDURE - LIFT ASSIST AND PANTOGRAPH



10. Raise the "Lift Assist" arms until fully extended.



WARNING:

Do not use the "Lift Assist" unless both arms are in full contact with the truck or trailer bed. This is dependent on load position at the front and rear of the truck/trailer. If there is insufficient space to use the "Lift Assist", the operator must drive to the other side of the truck or trailer to finish unloading.



WARNING:



Do Not Use the "Lift Assist" if unloading from unpaved or uneven surfaces.

11. Raise the load slowly just enough to clear the bed.



WARNING:

Do not lift the load more than 100mm clear of the bed while the pantograph is extended.



12. Sideshift enough to clear the adjacent pallet or headboard.

13. Retract the pantograph fully.

14. Double fork if necessary to ensure load is in contact with fork face.


15. Tilt the mast rearward enough to stabilise the load.

16. Lower "Lift Assist" arms fully.


17. Retract the mast fully.

18. Raise the stabilisers fully.


B4. OPERATING PROCEDURE - LIFT ASSIST AND PANTOGRAPH



19. Ensure the rear wheel is pointing straight ahead.
20. Reverse straight back to clear the truck or trailer bed (looking in the direction of travel).



21. Lower the load to a level just above the frame.
22. Sideshift the mast to the centre position.
23. Lower the load as low as possible within the frame.



24. Turn the forklift in the intended direction of travel.
25. Slowly drive away – looking in the direction of travel.


B5. MOUNTING PROCEDURE - LIFT ASSIST AND PANTOGRAPH

Mounting Machine

When mounting this machine standard Mounting Procedure applies however the Lift Assist and Pantograph machine is fitted with a pressure sensor in the rod side of the lift cylinder. This sensor detects when the machine is lifted off the ground during truck mounting. When the sensor detects pressure e.g the machine is lifted off the ground the pantograph is disabled. This stops the pantograph being used to mount or dismount the machine on the mounting kit.


If the machine is mounted with the pantograph extended the machine will lift however the pantograph function will be disabled. To continue mounting the machine you must first lower the machine to the ground and then fully retract the pantograph. Continue to mount the machine with the pantograph retracted.

NEVER mount the machine using the pantograph always ensure the pantograph is **FULLY** retracted.



B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH


Grease Points



ITEM	DESCRIPTION	No. OF POINTS	PAGE NUMBER	ITEM	DESCRIPTION	No. OF POINTS	PAGE NUMBER
1	Lift Cylinders	2	114	5	Scissor Middle Section	1	118
2	Mast Outer	4	115	6	Scissor Rear Section	4	119
3	Mast Inner	6	116	7	Scissor Front Section	3	120
4	Pantograph Mast	4	117	8	Pantograph Cylinder	2	121


B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON LIFT CYLINDERS




B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON MAST OUTER SECTION




B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON MAST INNER SECTION



B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH


GREASE POINTS ON PANTOGRAPH MAST SECTION



B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH


GREASE POINTS ON PANTOGRAPH ARM

Location of pantograph arm on machine




B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON PANTOGRAPH ARM




B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON PANTOGRAPH ARM



B6. MAINTENANCE - LIFT ASSIST AND PANTOGRAPH

GREASE POINTS ON PANTOGRAPH EXTENSION CYLINDER






Operator Manual

Moffett Truck Mounted Forklift 4-Way Machines

Note:

This section of the manual describes additional operating instructions for the Moffett Truck-Mounted Forklift 4-Way unit and should only be used as a supplement to the operator manual.




Delivering **Confidence**

C. INTRODUCTION – 4-WAY STEERING

Overview of 4-Way Steering System


In addition to conventional direction travel Forward and Backward (**2-Way Mode** - front wheels locked straight ahead and rear wheel steering) this machine is also fitted with two front steering cylinders.

These front steering cylinders enable the machine to travel sideways (**4-Way Mode** - rear wheel locked to 90° front wheels steering). When the machine is in 4-Way Mode the front steering cylinders are connected in Series. The larger RH cylinder full bore side feeds into the LH cylinder rod side when steering to straight ahead and vice versa when turning to 90°.



Forward Mode Of Operation

2-WAY MODE



Lateral Mode Of Operation

4-WAY MODE

C1. SAFETY CHECKLIST – 4-WAY STEERING

Safety Checklist



WARNING:

Using This Manual

This section of the manual describes additional operating instructions for the Moffett Truck-Mounted Forklift 4-Way unit and should only be used as a supplement to the operator manual.



WARNING:

Travelling.

NEVER Travel in 4-Way mode without a load.
NEVER Change modes when machine is moving.
Without a load, travel in normal mode with the mast fully extended.



WARNING:

Using 4-Way.

Change into and out of 4-Way mode on a firm level surface. Never change modes while the machine is moving. Always apply Park Brake before changing steering modes.



WARNING:

Travelling On Inclines.

When on an incline, the combined centre of gravity moves downhill. In 4-Way mode the combined centre of gravity will be closer to the edge of the stability triangle and the stability is reduced.

Reference Page 137. Operating on Inclines and Unusual Ground Surfaces.



CAUTION:

Operating the Machine.


Do not extend the mast carriage when travelling in 4-Way mode.

Do not select the 4-Way mode when the mast carriage is extended.


Always ensure forks are central and either fully down or above the frame prior to changing into 4-Way.

C2. INTRODUCTION – 4-WAY STEERING

Safety Decals



Location of 517.100.0072



Location of 517.062.0001

Part No. 517.100.0072

IMPORTANT

TO CHANGE STEERING MODES 2WAY & 4 WAY:

- ENGAGE PARK BRAKE SWITCH
- SELECT 2W-4W SWITCH POSITION
- PRESS THE MODE BUTTON TO MOVE THE WHEELS.


NOTE: IF THE MACHINE IS TO BE USED FOR LONG PERIODS IN 2WAY MODE THEN THE FOLLOWING PROCEDURE MUST BE CARRIED OUT DAILY:

- IN 4WAY TURN THE FRONT WHEELS **FULLY** INWARDS UNTIL THEY REACH THE MECHANICAL STOP AND CONTINUE TO TURN THE STEERING AGAINST THE END STOP FOR APPROX. 20 SECONDS.

THIS PURGES AND RESETS THE 4-WAY SYSTEM ENSURING BOTH HYDRAULIC CYLINDERS ARE SYNCHRONIZED.

NOTE: IF ANY LOSS OF ALIGNMENT IS NOTICED BETWEEN THE FRONT STEERING CYLINDERS THEN CARRY OUT THE ABOVE PROCEDURE TO RESET THE STEERING CIRCUIT AS REQUIRED.


517.100.0072



Accumulator decal 517.062.0001

C2. INTRODUCTION – 4-WAY STEERING

Safety Decals (continued)



Location of 517.106.0000

Part No. 517.106.0000




- ——— 4 WAY SWITCH
- ——— CARRIAGE LIMIT SWITCH
- ——— REAR PRESSURE SWITCH
- ——— MAST PROX SWITCH
- ——— FRONT PRESSURE SWITCH
- ——— BACKUP POWER

517.106.0000

Note: The status of the 4-Way system as well as simple fault finding can be seen by the colour of the LED's on the control module.

C2. INTRODUCTION – 4-WAY STEERING

Instruments and Controls





C3. CENTRE OF GRAVITY – 4-WAY STEERING

Stability Triangle


The Stability of this machine is greatly reduced in lateral 4-Way mode. As per the diagram below when the front wheels are turned into 4-Way mode the stability triangle is reduced. This means that the Centre of Gravity has less distance to travel before it leaves the Stability triangle and the machine could become unstable. Dimensions A and B in the diagram below show how the lateral stability is reduced when in 4-Way mode.

Note: On this machine counterweights are fitted in the wheel rims to compensate for some of this reduction in stability.

 C.O.G. = Centre of Gravity



Normal 2-Way Mode




4-Way Mode

C3. CENTRE OF GRAVITY – 4-WAY STEERING


Note: The width of the Stability Triangle is reduced when the lateral (4-Way) mode is engaged. This creates a narrower stability pyramid compared to when the Moffett is in Normal (2-Way) mode, causing the forklift to become less stable laterally as the load is elevated. This is why the lift height is restricted to 2m to maintain an optimum level of lateral stability (see below).

LIFT HEIGHT RESTRICTION




WARNING


NEVER TRAVEL IN THE LATERAL MODE WITH AN ELEVATED LOAD.




C4. OPERATING PROCEDURES – 4-WAY STEERING




NORMAL MODE 2-WAY



4-WAY MODE



Forward Mode Of Operation



Lateral Mode Of Operation


C4. OPERATING PROCEDURE – 4-WAY STEERING

Instruments And Controls

Changing Steering Modes

All machines can be changed from 2-Way to 4-Way steering mode by following the sequence below. The machine can be changed semi automatically using the Mode button or manually using the steering wheel.

A. Mode Button Operation



Note: The Mode button will only work if the machine is stationary and the electric park brake is applied as the park brake interlocks the function of the Mode button.

A1. Changing from 2-Way to 4-Way

1. Ensure machine is stationary on level ground
2. Apply the electric PARK BRAKE.
3. Change 4-Way switch to 4-Way position.
4. Push red MODE button until rear wheel moves to 90° position then release.
5. System will automatically change oil to front wheels.
6. Continue to press red MODE button until front wheels are at 90° then release.
7. Release park brake ready to drive.
8. Machine is now in 4-Way Mode.

A2. Changing from 4-Way to 2-Way

1. Ensure machine is stationary on level ground
2. Apply the electric PARK BRAKE.
3. Change mode switch to 2-Way position.
4. Push red MODE button until front wheels come to straight ahead position then release.
5. System will automatically change oil to rear wheel.
6. Continue to push red MODE button until rear wheel is in the straight ahead position then release.
7. Release the park brake ready to drive.
8. The machine is now in 2-Way Mode.

C4. OPERATING PROCEDURE – 4-WAY STEERING

Instruments And Controls (continued)

Changing Steering Modes (continued)

B. Manual Operation

B1. Changing from 2-Way to 4-Way

1. Ensure machine is stationary on level ground.
2. Apply electric PARK BRAKE.
3. Steer rear wheel to 90° position using the steering wheel.
4. Change the 4-Way switch to 4-Way position.
5. Steer front wheels to 90° using the steering wheel.
6. Release park brake ready to drive.
7. Machine is now in 4-Way Mode.

B2. Changing from 4-Way to 2-Way

1. Ensure machine is stationary on level ground.
2. Apply electric PARK BRAKE.
3. Steer front wheels to straight ahead using the steering wheel.
4. Change the 4-Way switch to 2-Way position.
5. Steer rear wheel to straight ahead position using the steering wheel.
6. Release the park brake ready to drive.
7. The machine is now in 2-Way Mode.

Note: Always change steering modes using minimum engine revs, this ensures the pressures raised in the rear steering ram are kept to a minimum.

If changing steering modes in extremely deep mud or severe ground conditions then higher than normal steering pressures could be generated in the steering lines. These higher pressures may trigger the pressure switches in the automatic system before the steering wheels have fully reached their stops. If this occurs then change back to the previous steering mode and manually steer the wheels fully to the stops before switching to desired steering mode. If the rear arm will not steer manually then the ground conditions are too severe to change steering modes the operator needs to find improved ground conditions before changing steering modes.


Also if the machine is used in very cold conditions always ensure that the machine is warmed up fully before attempting to change steering modes as the cold oil will also create higher than normal steering pressures.

C4. OPERATING PROCEDURE – 4-WAY STEERING


Instruments And Controls (continued)

The relays which control the functions of the 4-Way steering system are also linked to 6 LED's which can be seen on the control module located under the front lip of the pedal enclosure.

The function and colour of these LED's is outlined below and they can be used to check the status of the 4-Way system as well as simple fault finding.



Control Module LED Decal



LED Function and Colour

- A – Green if 4-Way switch is in the 4-Way mode.
- B – Green if Carriage is back ready for mode change.
- C – Green if Rear Pressure switch is activated.
- D – Green if Mast height is below limit.
- E – Green if Front Pressure switch is activated.
- F – Green if Power is ON to Control Module.

If any of the LED's do not light up green as outlined above then refer to Section C7. Special Procedures.

C4. OPERATING PROCEDURES – 4-WAY STEERING

Lifting A Wide Load

- Approach the trailer in 2-Way mode with the mast fully extended.
- Make sure the load to be lifted is stable and secure.
- Check the weight and load centre of the load to be lifted. If the weight is not marked or shown on the load, check the weight with your supervisor or have it weighed. If it is too heavy, split the load and restack it.
- Centre the forks as wide as possible to suit the load.
- Extend the mast carriage fully.
- Fold down the load supports.
- (While pushing the load support back, open the anti loose fastener and lower the load rest to the machine frame).
- Align the forks with the centre of the load, approach it squarely and drive into the load until the forks are fully engaged.
- Check that the ground surface is strong enough to support the stabilisers.
- Lower the stabilisers fully.
- Raise the load to clear the truck / trailer bed.
- Tilt the mast rearward to secure the load.
- Sideshift the mast to the centre position.
- Retract the mast fully to bring the load above the front wheels.
- Raise the stabilisers fully
- Back away slowly to ensure the load clears the truck / trailer bed.
- Apply the parking brake.
- Lower the load onto the load rests, keeping the forks in contact with the bottom of the load.
- Ensure the machine is on a firm level surface.
- Change to 4-Way mode.
- Disengage the parking brake. The machine can now be driven in 4-Way mode.
- Depress the pedal (toe) forward to move the machine to the right, depress the pedal (heel) back to move the machine to the left.

C4. OPERATING PROCEDURES –PLACING A WIDE LOAD

Placing A Wide Load

- When travelling in 4-Way mode with wide load that needs to be placed.
- First ensure the placement area is a firm level surface.
- Check that the area is clear of debris.
- Approach the final position squarely.
- Apply the parking brake.
- Raise the load until it clears the load rests.
- Change to 2-Way Mode.
- Check that the ground surface is strong enough to support the stabilisers.
- Lower the stabilisers fully.
- Extend the mast fully to clear the frame, wheels and load rests.
- Lower the forks to the ground to deposit the load
- Tilt the mast forward slightly to deposit the load.
- Raise the stabilisers fully.
- Disengage the parking brake.

- Check that the rear wheel is in the straight ahead position.
- Back up carefully.
- Drive slowly facing the direction of travel keeping the mast fully extended.



WARNING:

No Load. Never travel in 4-Way mode without a load on the forks. Always change to Normal 2-Way mode when travelling with No Load and ensure the mast is fully extended.

C4. OPERATING PROCEDURE – 4-WAY STEERING

Operating On Inclines And Unusual Ground Surfaces.

- Do not travel in 4-Way mode without a load.
 - Do not travel across an incline in 4-Way mode.
 - Always approach an incline to the left and travel up and down the incline. Drive up an incline to the left. Drive down an incline to the right.
 - Keep the operators compartment facing uphill.
 - Do not turn on an incline
 - Never stop or start suddenly.
 - Operate all controls smoothly.
 - Watch out for potholes or other obstacles that could affect the stability of the machine.
- Drive slowly over rough terrain.
 - Where necessary, engage the diff-lock and travel slowly for additional traction.
 - Always take great care when transporting wide loads on any incline. Carry the load on the load rests keeping the forks in contact with the bottom of the load.
 - Make allowances for the reduction in both stability and lift capacity when operating on inclines.
 - Remember that a machine in 4-Way mode is less stable than in normal mode.
- Do not attempt to drive up or down an incline in 4-Way mode just because you have driven up or reversed down in normal mode.
 - Only use 4-Way mode when it is not otherwise possible to carry a wide load.

C4. OPERATING PROCEDURES - OPERATING ON INCLINES



WARNING:

On 4-Way Models:


- Change into and out of 4-Way mode on a firm level surface only.
- Never travel in 4-Way mode without a load.




WARNING:

When on an incline, the combined centre of gravity moves downhill. In 4-Way mode the combined centre of gravity will be closer to the edge of the stability triangle and stability is reduced.

DRIVE UP TO THE LEFT
→



DRIVE DOWN TO THE RIGHT
→




C. 4-Way Mode - Mast Fully Retracted - With Load

C4. OPERATING PROCEDURES - OPERATING ON INCLINES

Operating on Inclines (continued)

Note: When travelling on an incline the combined centre of gravity moves downhill. In 4-Way mode the combined centre of gravity will be much closer to the edge of the stability triangle as the machine is travelling sideways. This means the stability of the machine will be reduced.



C4. OPERATING INSTRUCTIONS – 4-WAY STEERING

Load Supports

The 4-Way machine is fitted with Load Supports, these are used in conjunction with wide loads to minimize load deflection and increase load stability.




WARNING:

Never travel in the lateral (4-Way) mode with an elevated load. Always keep the load as low as possible.

Never travel in Lateral (4-Way) mode with no load on the forklift.

Note: Always fold up the Load Supports before transporting the machine.



C4. OPERATING THE 4-WAY MACHINE – POINTS TO REMEMBER

Points To Remember:

Ensure you are on a firm and level surface before engaging the lateral (4-Way) mode.

Only use lateral (4-Way) mode where it is not possible to otherwise carry a wide load.

Never travel in 4-Way mode without a load.

Always carry the load on the forks AND the load supports.

Never start or stop suddenly. Operate all controls smoothly.

Watch out for potholes or other obstacles which could affect the stability of the forklift.

Drive slowly over rough terrain.

Where necessary, engage the difflock and travel slowly for additional traction.

Never travel in 4-Way mode with and elevated load, always keep load as low as possible.

Never turn on an incline.

Always keep the operators compartment facing uphill when travelling on inclines.

Do not attempt to drive up or down an incline in 4-Way mode just because you have driven up or reversed down previously in normal mode.

Always return to the normal mode (2-Way) before placing a load.

Before Selecting 4-Way (Lateral) Mode

1. Ensure machine is stationary.
2. Ensure mast carriage is fully retracted.
3. Ensure the stabilisers are fully raised.
4. Ensure the load is above the height of the wheels.



While In 4-Way (Lateral) Mode

1. Do not extend mast carriage.
2. Do not use stabilising legs.
3. Transport the load as low as possible above the wheels.
4. Operate the forward / reverse pedal as smoothly as possible.
5. **The light on the 4-Way switch signifies that you are in 4-Way mode, as well as the 4-Way work lights and beeper being activated.**

C5. MOUNTING PROCEDURE – 4-WAY STEERING


Mount as per standard machine (See section 5)

Note: During the truck mounting/dismounting sequence never engage 4-Way mode as serious damage will occur to the mounting kit and the machine.



C6. MAINTENANCE – GREASE POINTS


FRONT STEERING CYLINDERS



Note. Refer to the standard operator manual for the standard grease points on the machine.


C6. MAINTENANCE – GREASE POINTS

FRONT STEERING SWIVELS



C6. MAINTENANCE – GREASE POINTS

CARRIAGE BEARING BLOCKS



C6. MAINTENANCE

Daily Maintenance Inspection

In addition to the daily maintenance inspection that is listed in the standard operator manual, some additional daily checks should be carried out on 4-Way machine.

Before you begin your work day take time to check your machine and make certain that the front steer system is in good operational condition.

Please carry out the following procedure:

On the series steer circuit daily turn the wheels fully inwards to the 4-Way position until they reach the mechanical stop. Continue to turn the steering against the end stop for approximately 20 seconds.


This purges and resets the 4-Way system ensuring both hydraulic cylinders are synchronized.

Note: If the machine is to be used continuously then carry out the above sequence at one hour intervals of operation.

Alternatively if any loss of alignment is noticed between the front two steering cylinders, carry out the above procedure to reset the steering circuit.

C7. SPECIAL PROCEDURES

4-Way Override Procedure



Location of 4-Way controller

In the event of a 4-Way system failure, a back up procedure is available on your machine to allow you to continue to operate the 4-way function manually until the machine can be serviced.

First check that all the 4-Way LED's on the Control Module are working as they should. If they are all OK then check the 4-Way fuse has not blown and if this is intact then the following procedure can be carried out.

1. Remove the 4-Way controller from the inside of the pedal enclosure as shown above.
2. Take the 4-Way override connector, this is tie wrapped to the wiring loom behind the steering column.
3. Plug the 4-Way override connector into the wiring loom at the same location the 4-Way controller has been removed from. The override connector is colour coded (black) to connect into branch eight of the wiring loom.
4. The 4-Way function can now be operated manually as described in the operation procedures.

CALIFORNIA

Proposition 65 Warning

**Diesel engine exhaust and some of its
constituents are known to the State of California
to cause cancer, birth defects and other
reproductive harm**



Moffett Engineering Ltd
Ardee Road, Dundalk, County Louth, Ireland
Tel: +353 (0)42 9359500 Fax: +353 (0)42 9359590
Email: moffett.forklift@hiab.com Website: www.hiab.com/forklifts

A Hiab Company